

lexicon

MPX 100 Dual Channel Processor

Stereo 44.1kHz S/PDIF Digital Output

User Guide

Unpacking and Inspection

After unpacking the unit, save all packing materials in case you ever need to re-ship. Thoroughly inspect the unit and packing materials for signs of damage. Report any shipment damage to the carrier at once; report equipment malfunction to your dealer.

Notice

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J of Part 15 of FCC Rules, which are designated to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures: reorient the receiving antenna; relocate the computer with respect to the receiver; move the computer away from the receiver; plug the computer into a different outlet so that the computer and receiver are on different branch circuits. If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful: "How to identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, DC 20402, Stock No. 004-000-00345-4.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la class B prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

Acknowledgement

All product names indicated by a Trade Mark are registered by their respective manufacturers.

Copyright ©1998, Lexicon Inc.
All Rights Reserved.

Lexicon Part #070-11935

Lexicon Inc.
3 Oak Park
Bedford MA 01730 USA
Telephone 781-280-0300
Fax 781-280-0490

Table of Contents

Getting Started	1	Program Descriptions	17
Introduction	1	Single Programs	18
Front Panel Overview	2	Dual Programs	32
Setting Audio Levels		Special FX	41
Rear Panel Connections	4	User Programs	42
Audio Connections • Headphones • Footswitch		Restoring Factory Defaults	
Basic Operation	7	MIDI Operation	43
Selecting Programs	7	MPX 100 MIDI Behavior	43
Single Programs • Dual Programs • User Programs		Assigning a MIDI Channel for Program Load	44
Editing	9	Using Program Change Messages for Program Load	
Tap Tempo Functions: Varying the rhythm • Audio		Learning Continuous Controllers	46
Tap • Setting Tempo via MIDI		Activating Bypass or Tap Functions with Program Change	
Bypass	11	Messages	47
Storing Programs	12	Clearing a Learned Assignment	48
System Mode	13	MIDI Clock	49
System Mode Parameters	14	MIDI Dumps	49
Bypass • Patching • Program Load • Digital Output		MIDI Implementation Chart	50
MIDI OUT/THRU • MIDI Pgm Change • MIDI Clock		Specifications	52
Receive • Tempo • MIDI Dumps			

Introduction

Thank you for your purchase of the MPX 100 Dual Channel Processor.

The MPX 100 is a true stereo dual-channel processor with 24-bit internal processing, 20-bit A/D-D/A and S/PDIF digital output. Powered by a new version of Lexicon's proprietary Lexichip™, the MPX 100 has 240 presets with classic reverb programs such as Ambience, Plate, Chamber and Inverse, as well as Tremolo, Rotary, Chorus, Flange, Pitch, Detune, 5.7 second Delay and Echo. Dual-channel processing gives you two independent effects in a variety of configurations: Dual Stereo (Parallel), Cascade, Mono Split and Dual Mono.


A front panel Adjust knob allows instant manipulation of each preset's critical parameters and an Effects Lvl/Bal knob lets you control effect level or the balance of dual effect combinations. An easy Learn mode allows MIDI patching of front panel controls. In addition, tempo-controlled delays and modulation rates lock to Tap or MIDI clock, and Tap tempos can be controlled by audio input, the front panel Tap button, dual footswitch, external MIDI controller or MIDI Program Change.

Getting Started

Other features include dual 2-stage headroom indicators, a headphone output, a software-selectable MIDI OUT/THRU port, pushbutton or footswitch selection of dry or muted audio output and a 20Hz-20kHz ±1dB Frequency Response.

To make sure you get the most out of the MPX 100, be sure to read the manual.

Front Panel Overview



Setting Audio Levels

1. Start with INPUT set to 9:00 o'clock and OUTPUT all the way down (fully counter-clockwise).
2. Set the instrument output or effects send being input to the MPX 100 to a nominal level and play, or send audio to the MPX 100. The Level LEDs* should light green. If the Clip LEDs light red at this point, turn down the output of the instrument or effects send until the Clip LEDs remain off during the loudest passages.

3. While still sending audio to the MPX 100, gradually turn up the INPUT control until the Clip LEDs show red on only the loudest peaks.
4. Set the MIX control to **Dry**.
5. Turn OUTPUT to the desired level.
6. If the MPX 100 is using a console's sends and returns, set the MIX control fully clockwise (100% wet). If you are using an instrument amplifier, start with MIX set halfway up.

* The Level LEDs are off when the incoming signal is low (more than 30dB below overload). The Clip LEDs light red when the signal approaches overload (-2.5dB). Acceptable signals will cause the Level LEDs to light green almost continuously, with the Clip LEDs flashing red on peaks.

As with any audio product, it is good practice to first power on all outboard gear, then the mixer, then any loudspeakers.

Rear Panel Connections

MIDI
Two 5-pin DIN MIDI connectors are provided for MIDI IN and software selectable MIDI OUT/THRU.


POWER
Use Lexicon 9VAC power pack.

DIGITAL OUTPUT
RCA S/PDIF connector.

OUTPUT
Single-ended (unbalanced) stereo outputs provide +8dBu typical output level. Use the right output connector for mono output. If no connection is made at the right output, the left output can be used to drive headphones at modest volume.



FOOTSWITCH
1/4" TRS connector, for momentary contact footswitch, allows footswitch control of front panel Tap and Bypass functions.



INPUT
Single-ended (unbalanced) inputs accept levels as low as -30dBu. Input impedance is 500 kΩ. Use the right input for mono sources. Can be used as direct input for guitar.

Audio Connections

Audio connections to the MPX 100 are unbalanced and should be made with high quality shielded cables with 1/4" tip-sleeve phone plugs at the MPX 100 end.

The MPX 100 produces effects from either mono or stereo sources. With mono sources, the dry signal appears, along with audio effects, at both outputs. For instruments and sources with stereo outputs, use both inputs. We recommend using the outputs in stereo whenever stereo inputs are used, but if mono output is required, use the right output jack. The left and right signals are summed internally when only the right output is used.


Headphones

A stereo signal which is adequate to drive headphones is available at the left output (provided no connections are made through the right output). This feature is provided as a convenience for practice purposes, and is intended to provide only modest volume.


Footswitch

A footswitch connected via the rear-panel footswitch jack allows control of Tap and Bypass. A momentary footswitch can be wired to a tip-ring-sleeve connector. A stereo Y-connector allows two identical single switches to be used.



Power off the MPX 100 before plugging in the footswitch. (Otherwise, Bypass will be enabled.)



Connecting to a Balanced Console



The MPX 100 can be used as two independent Effects Processors with Dual Program Variations 11-16. Designate two auxiliary sends on your console and connect one to the left MPX 100 input, and the other to the right input. Refer to the Program Descriptions to take advantage of this configuration.



Basic Operation

Selecting Programs

All of the programs on the MPX 100 are selected with the front panel PROGRAM and VARIATION knobs.

The PROGRAM knob selects Single or Dual program banks. The VARIATION knob selects different program versions.

The Single selections are arranged around the left side of the PROGRAM knob; the Dual selections and the User bank are arranged around the right side of the knob.

Single Programs

When a Single program is selected, turning the VARIATION knob to positions 1-8 will load eight versions of the first effect; positions 9-16 will load eight versions of the second effect.




For example, when **Plate, Gate** is selected, VARIATION 1-8 will load eight different Plate programs; VARIATION 9-16 will load eight different Gate programs.

When Special FX is selected, the VARIATION knob will load 16 different programs (one at each knob position).

Use the PROGRAM knob to select the Single, Dual or User effect you want.



Turn VARIATION to select one of 16 programs.



Dual Programs



When one of the Dual Programs is selected, the VARIATION knob will load 16 different programs, each containing two effects.

User Programs

When **User** is selected with the PROGRAM knob, VARIATION selects 16 memory locations available for storing your own programs.




(When shipped, User variations 1-16 contain duplicates of a selection of the factory-installed programs.)

Editing

Editing MPX 100 programs is easy. We've arranged the critical parameters of each program under the front panel **Adjust** knob, so all you have to do is turn the knob to adjust the program to suit you.

You can also adjust the level of the Single programs, or the Effects Balance of the Dual programs with the **Effects Lvl/Bal** knob.

Changes made with either knob are recognized as edits, and will cause the front panel **Edit** LED to light to alert you to the fact that the program has been altered.



Tap Tempo Functions

Varying the Rhythm

The MPX 100 Tap Tempo feature allows you to set the delay times and modulation rates of tempo-based programs to the beat of the music.

To set the tempo from the front panel, simply press the **Tap** button twice in time with the music. That's your tempo. No more dialing up what "could be" the delay time in milliseconds—just tap twice—the MPX 100 will figure out the time for you. When you want to change tempo, just tap twice again in the new rhythm.



*The **Tap** LED will flash whenever a tempo-based preset is loaded.*

Audio Tap

You can also use audio input to set the tempo of the MPX 100 delay times.

1. Press and hold the **Tap** button for two seconds. (The optional dual footswitch lets you press and hold **Tap** without taking your hands off your instrument.)
2. While holding down **Tap**, play 2 short notes in rhythm, then release the **Tap** button.
3. The MPX 100 automatically calculates the tempo from the space between your two notes.

For live performances this is a must — an easy way to set delay rates to follow your rhythm.

Many factory programs are stored with their own tempo rate. You can tap in a new tempo (and store your version in a User location) or set the MPX 100 to always recall the last tempo used and apply it to every program. (See **System Mode**.)

When you select Global Tempo from the MPX 100 System mode, the last tempo tapped in will be applied to all programs with tempo-controlled parameters. (You will know if a program is tempo-controllable because the **Tap** button LED will flash when the program is loaded.)

Setting Tempo via MIDI

When used in conjunction with the *Learn* feature, Tap can be set remotely from any MIDI device. MIDI controllers, such as Lexicon's MPX R1 Foot Controller, can be used to send Continuous Controller messages or Program Changes to the MPX 100 or you can send Continuous Controller or Program Change messages from the button and fader moves of many mixing consoles. The MPX 100 will Learn these messages and allow you to set tempo via MIDI.

The MPX 100 can also receive and utilize MIDI Clock. So, when used with a MIDI sequencer or drum machine, the MPX 100 automatically adjusts its internal tempo to match. (See *MIDI Operation*.)

Bypass

Pressing the front panel **Bypass** button will cause the MPX 100 to pass only dry, unprocessed audio, or to mute the inputs to the current effect.



Bypass can be set to mute or bypass effects.


A System Mode parameter determines which of these two options is in effect. (See *System Mode*.) Bypass functions can also be activated by footswitch or via MIDI.

Storing Programs

When you want to save a program, press **Store**. The **Store** LED will flash slowly to indicate that the MPX 100 store function is armed. (If you want to exit without saving the current program, press **Store** again.)

Turn the PROGRAM knob to **User**, then use VARIATION to select one of the 16 User locations.

Press **Store** again to save your program to the selected location (and overwrite the program previously stored there). The **Store** LED will flash rapidly while the store operation is completed. The store operation is complete when the LED stops flashing and turns off. The Edit LED will also turn off, as the current program is now your saved version.



System parameters and MIDI dumps are activated in System mode. To enter this mode, press and hold **Bypass** for approximately 2 seconds. The **Bypass** and **Store** LEDs will blink slowly to indicate you are in System mode.

The adjustable parameters available in this mode are shown in the chart on the following page.


Turn the VARIATION knob to select a parameter. Press **Store** to toggle the state of the parameter, or to execute a MIDI dump. The **Edit** LED will show the current state of each parameter.

System Mode


When you have finished editing parameters and are ready to resume normal operation, return the VARIATION knob to its prior setting, or you will load a new program based on its position when you exit System Mode. (The **Tap** LED will light when VARIATION matches its prior setting.)

To exit System Mode, Press **Bypass**. If you have changed any System parameters, the **Store** LED will flash rapidly.


Press and hold **Bypass** for 2 seconds...



Turn **VARIATION** to select a parameter.



Press **Store** to toggle the parameter state (or to execute a MIDI dump).



System Mode Parameters

Variation Setting	Parameter	State when Edit LED is:	
		On	Off
1	Bypass	Mute	Bypass*
2	Patching	Disabled	Enabled*
3	Program Load	Mute	Bypass*
4	Digital Output	Dry	Wet*
5	MIDI OUT/THRU	Out*	Thru
6	MIDI Pgm Change	Disabled	Enabled*
7	MIDI Clock Receive	Disabled	Enabled*
8	Tempo	Program*	Global

MIDI Dumps (Press Store to Transmit)

- 14 Dump User Programs
- 15 Dump Current Program
- 16 Dump System and Learned patches

* Factory Default

Turn **VARIATION** until the **Tap** LED goes on to find the last loaded program...then press **Bypass** to exit System Mode.



System Mode Parameters

1 **Bypass** **Mute/Bypass**

This parameter sets the **Bypass** button (or the footswitch, or MIDI controller assigned to **Bypass**) to mute the inputs, or to bypass the processed audio (passing only dry audio to the outputs).

2 **Patching** **Disable/Enable**

This parameter allows you to temporarily suspend (Disable) and restore (Enable) any Learned patches.

3 **Program Load** **Mute/Bypass**

This parameter determines whether the MPX 100 will engage wet mute or simply bypass processed audio during program load.

4 **Digital Output** **Dry/Wet**

For certain recording and monitoring applications, this parameter allows you to choose to pass only dry audio, or to resume output of the full, processed signal.

5 **MIDI OUT/THRU** **Out/Thru**

Sets the rear panel MIDI OUT/THRU jack for either MIDI OUT or MIDI THRU functionality.

6 **MIDI Pgm Change** **Disable/Enable**

The setting of this parameter determines whether or not the MPX 100 will recognize MIDI Program Change messages for loading programs.

7 **MIDI Clock Receive** **Disable/Enable**

The setting of this parameter determines whether or not the MPX 100 will recognize MIDI Clock messages.

8 **Tempo** **Program/Global**

Determines whether the current tempo of the MPX 100 will be applied to all programs (Global), or whether program-specific tempos are restored on each program load.

14-16 **MIDI Dumps**

These selections allow you to execute MIDI Dumps. See *MIDI Operation*.


Program Descriptions

The 240 programs in the MPX 100 are designed to provide a full palette of high caliber ambience, reverb, delay, pitch shift and other effects. As you audition the programs, be sure to vary the **Adjust** knob.

The **Adjust** knob has been carefully customized for each individual program. In many cases it controls several effect parameters simultaneously to provide simple control of a complicated editing process. In many Chamber and Room programs, for example, **Adjust** controls the "liveness" of the space by changing decay, EQ and early reflections all at the same time.

The behavior of the **Adjust** knob is also customized for different functions. Sometimes it acts as a linear control (at its minimum value when turned fully counterclockwise—like a volume control) and sometimes it acts as a bi-polar control (at its minimum value when centered—like a cut/boost EQ control).

The following section provides a general description of each MPX 100 program along with tables that detail all of the program variations available with the VARIATIONS knob. These details include the function of the **Adjust** knob and the **Tap** button (for variations that use tempo-controlled rate or delay times).









	Plate VARIATIONS	Adjust 	Tap 
1	Small Plate	Liveness	–
2	Medium Plate	Liveness	–
3	Large Plate	Liveness	Predelay (1/32 Note)
4	Larger Plate	Decay Time	Predelay (1/32 Note)
5	Tape Slap Plate	± Decay/15ips or 7.5ips	–
6	Rich Plate	Decay Time	Predelay (1/32 Note)
7	Large Bright Plate	Decay Time	Predelay (1/32 Note)
8	Vocal Plate	Low Cut, Decay Time	Echo

Plate reverb was originally generated by a large, thin sheet of metal suspended upright under tension on springs. Transducers attached to the plate transmitted a signal that made the plate vibrate — making sounds broadcast through the plate seem to be occurring in a large open space.

Plate

The Plate program in the MPX 100 synthesizes the sound of metal plates with high initial diffusion and a relatively bright, colored sound. This program is designed to be heard as part of the music, mellowing and thickening the initial sound. It is a popular choice for enhancing popular music, particularly percussion.




	Gate VARIATIONS	Adjust 	Tap 
9	Straight Gate	Duration*	–
10	Drum Gate	Duration*	–
11	Slope Down	Duration*	–
12	140 ms Gate	High Cut	Predelay (1/32 Note)
13	240 ms Gate	High Cut	Predelay (1/32 Note)
14	340 ms Gate	High Cut	Predelay (1/32 Note)
15	440 ms Gate	High Cut	Predelay (1/32 Note)
16	540 ms Gate	High Cut	Predelay (1/32 Note)

Gated reverbs were originally created by feeding a reverb, such as a metal plate, through an analog gate device. The decay time was set to instant, and the hold time varied the duration of the sound.

Gate

In the MPX 100, the Gate program provides a fairly constant sound with no decay until the reverb is cut off abruptly. This program works well on percussion — particularly on snare and toms, but be sure to experiment with other sound sources as well.




* Note that audio is muted briefly when Duration is altered with **Adjust**.

	Hall VARIATIONS	Adjust 	Tap 
1	Recital Hall	Decay	–
2	Small Church	Decay	–
3	Jazz Hall	Decay	–
4	Dance Hall	Decay	–
5	Synth Hall	Decay	–
6	Medium Hall	Decay	–
7	Large Hall	Decay	–
8	Large Church	Decay	–

Lexicon's Hall programs recreate the acoustics of actual places, from grand reverberant enclosures to small concert halls.

Hall




The clean reverberation of the Hall program is designed to add spaciousness, while leaving the source material unchanged. In addition to general instrumental and vocal applications, the Hall program is a good choice for giving separately recorded tracks the sense of belonging to the same performance.

	Chamber VARIATIONS	Adjust 	Tap 
9	Brick Wall	Liveness	–
10	Basement	Liveness	–
11	Live Concert	Liveness	Eko Delay
12	Percussion 1	Liveness	–
13	Percussion 2	Liveness	–
14	Live Chamber	Liveness	–
15	Vocal 1	Liveness	Eko Delay
16	Vocal 2	Liveness	Eko Delay

Historically, recording studio chambers were often oddly shaped rooms with a loudspeaker and set of microphones to pick up the ambience in various parts of the room.

Chamber

In the MPX 100, the stereo Chamber program produces an even, relatively dimensionless reverberation, with little change in color as the sound decays. The initial diffusion is similar to the Hall program, but the sense of space and size is much less obvious. This characteristic, along with the low color of the decay tail makes Chamber useful on a wide range of material. It is especially useful on spoken voice, giving a noticeable increase in loudness with very low color.




	Ambience VARIATIONS	Adjust 	Tap 
1	Voice Over	High Cut	–
2	Very Small Ambience	High Cut	–
3	Small Ambience	High Cut	–
4	Medium Ambience	High Cut	–
5	Studio D	High Cut	–
6	Bright Ambience	Decay Level	–
7	Dark Ambience	Decay Level	–
8	Marble Foyer	Liveness	–

Ambience gives warmth, spaciousness and depth to a performance without coloring the direct sound, and is commonly used to add a room sound to recorded music or speech.

Ambience

The Ambience program simulates reflections from room surfaces with random reflections, a gradual decay of overall level, and a gradual narrowing of the bandwidth.

The variations (1-8) provide a series of rooms in increasing sizes.












 VARIATION	Room VARIATIONS	Adjust 	Tap 
9	Bedroom	Wall Reflections	–
10	Tiled Room	Low Frequency Cut	–
11	Studio C	Liveness	–
12	Small Room	Liveness	–
13	Studio B	Decay Time	–
14	Rehearsal Room	High/Low Equalizer	–
15	Studio A	Decay Time	–
16	Large Room	High/Low Equalizer	–

The Room program emulates actual rooms where there is a more apparent sense of being in a small live place.

Room

The Room program is very useful on drums and percussion and can also be applied to electric guitar tracks.

The variations (9-16) provide a series of rooms in increasing sizes.

	Tremolo VARIATIONS	Adjust 	Tap 
1	Rectified Sine Wave 	Rate: 0.4-15Hz	–
2	Square Wave 	Rate: 0.4-15Hz	–
3	Sawtooth Wave 	Rate: 0.4-15Hz	–
4	Rectified Sine Wave 	Sweep: 0, 90, 180, 270	Rate (1/8 Note)
5	Square Wave 	Sweep: 0, 90, 180, 270	Rate (1/8 Note)
6	Sawtooth Wave 	Sweep: 0, 90, 180, 270	Rate (1/8 Note)
7	Triangle Wave 	Sweep: 0, 90, 180, 270	Rate (1/8 Note)
8	Sine Wave 	Sweep: 0, 90, 180, 270	Rate (1/8 Note)




Tremolo is a rhythmic change in loudness, commonly employed as an expressive technique by vocalists and wind instrument players. It is also one of the oldest electronic effects — frequently used with electric guitar, electric piano and, sometimes, vocals. Different tremolo effects are largely determined by the rate and waveform shape of the loudness change (fast or slow, smooth or sharp). If the effect is used in a stereo mix, the left and right can be synchronized in a variety of ways to produce dramatic side-to-side motion.

Tremolo

The MPX 100 tremolo variations offer a variety of tremolo shapes (square, sawtooth, triangle, sine and rectified sine). The synchronization of the left and right sides can be adjusted to produce mono and stereo effects. As the tremolo rates of several variations are set with Tap, it's easy to match the tempo of the music. Other variations let you set left and right channel waveforms out-of-phase, resulting in a panning motion.

All of the variations of this program (1-8) should be used with **Mix** set to fully Wet. By adding more dry to the wet/dry mix, **Mix** effectively sets the depth of the Tremolo.

As tremolo is essentially a rhythmic effect, care should be taken to make the rate work with the tempo of the music.

	Rotary VARIATIONS	Adjust 	Tap 
9	Rotary	Slow/Fast	–
10	Rotary	Slow/Fast, Width	–
11	Rotary	Slow/Fast, Balance	–
12	Slow Rotary	± Resonance	–
13	Varispeed Rotary	Speed	–
14	Tap Rotary	Balance	Rate (Quarter-Note)
15	Tap Rotary	Width	Rate (Quarter-Note)
16	Tap Rotary	± Resonance	Rate (Quarter-Note)




Rotary speaker cabinets were originally designed to provide a majestic vibrato/choir effect for electronic theater and church organs. The most well known rotary speaker is the Leslie™ Model 122, which has two counter-rotating elements — a high frequency horn and a low frequency rotor with slow and fast speeds. The sound generated as the spinning elements change speed is truly magical. The swirling, spacious effect is hard to describe, but is instantly recognizable.

Rotary

The MPX 100 rotary effect is a detailed simulation of a Leslie-style cabinet. The input signal is split into high and low frequency bands. The rotation effect is created by a synchronized combination of pitch shifting, tremolo and panning. Like the physical model, the high (horn) and low (drum) frequencies are “spun” in opposite directions. Horn and drum speeds are independent, and are designed with acceleration and deceleration characteristics to simulate the inertia of the original mechanical elements.

A virtual requirement for any organ sound, the rotary effect also sounds great with guitar and electric piano rhythm parts. In fact, it’s a great alternative to chorus and tremolo effects for any sound source.

All of the variations of this program (9-16) should be used with **Mix** set to fully Wet for the full effect.

	Chorus VARIATIONS	Adjust 	Tap 
1	Rich Chorus	± Resonance	–
2	Rich Chorus	± Depth	–
3	Rich Chorus	Rate	–
4	Rich Chorus	High Cut	–
5	Diffuse Chorus	Diffusion	–
6	Slap Chorus	Diffusion	–
7	Slap Chorus	± Resonance	–
8	Slap Chorus	± Depth	–




Chorus effects multiply the original audio source to create a lush, full sound. Traditionally used to fatten up tracks and to add body to guitar without coloring the original tone, chorus effects are also often used in combination with echoes, plates and other reverb effects.

Chorus

The stereo Chorus program uses six independently randomized delay voices panned across the stereo field. This program, inherited from Lexicon's PCM 80, generates a rich, airy effect that can simulate the sound of multiple sound sources from a single source.

This program is stunning on acoustic or clean electric guitar.

All of the variations of this program (1-8) should be used with **Mix** set to fully Wet to achieve the full richness of the 6-voice chorus.




	Flange VARIATIONS	Adjust 	Tap 
9	Light Flange: in phase sweep	± Resonance	—
10	Light Flange: out of phase sweep	± Resonance	—
11	Light Flange: in phase sweep	Rate	—
12	Light Flange: out of phase sweep	Rate	—
13	Deep Flange: in phase sweep	± Resonance	—
14	Deep Flange: out of phase sweep	± Resonance	—
15	Light Flange	Sweep: 0, 90, 180, 270	—
16	Deep Flange	Sweep: 0, 90, 180, 270	—

Flanging effects were originally created by simultaneously recording and playing back two identical programs on two tape recorders, then using hand pressure against the flange of the tape reels to slow down first one machine, then the other. The result was a series of changing phase cancellations and reinforcements, with a characteristic swishing, tunnelling and fading sound.

Flange

In the MPX 100, the stereo Flanger has two 2-tap delays—one per channel. The first tap is fixed, and the second sweeps past it. Mixing the two delay taps together creates the flanging effect.

All of the variations of this program (9-16) should be used with **Mix** set to fully Wet to achieve the full flange effect.




	Pitch VARIATIONS	Adjust 	Tap 
1	Semi-tone Shift	-2 to +1 octaves	—
2	Glide Shifter	± 1 octave	—
3	+/-100 cents	± 100 cents	—
4	Minor 3rd to 4th Harmony	Flat 3rd to 4th Up	—
5	4th/5th Harmony	4th to 5th Up	—
6	5th/6th Harmony	5th to 6th Up	—
7	2nd Inversion Triad	Minor/Major 3rd	—
8	Power Chords	Inversion	—

Altering the pitch of a sound allows a variety of effects from subtle detuning to the creation of harmonies and chords.

Pitch

The stereo polyphonic Pitch program in the MPX 100 allows complete program material or monophonic sources to be shifted down two octaves or up one octave.

For pitch correction, use this algorithm with **Mix** set to fully Wet. For harmonization, use the desired amount of wet/dry **Mix**.

 VARIATION	Detune VARIATIONS	Adjust 	Tap 
9	Mild	Detuning	–
10	Moderate	Detuning	–
11	Heavy	Detuning	–
12	FullRange	Detuning	–
13	Warm & Mild	Detuning	–
14	Warm & Moderate	Detuning	–
15	Warm & Heavy	Detuning	–
16	Slap Detuner	Detuning	–

Detune effects add a delayed/pitch shifted version of the original source — thickening up the sound. They can be particularly effective when used to simulate double-tracking. They are also great alternatives to chorus effects, adding the richness of a chorus without the audible sweep caused by the chorus rate.


Detune

The 4-voice stereo Detune program in the MPX 100 has one pair of voices per channel. As more detune amount is applied (with **Adjust**), the pair grow more out of tune, providing a lush sound without the need for a dry signal to be mixed in.

All of the variations of this program (9-16) should be used with **Mix** set to fully Wet to achieve the full effect.

Delay, Echo

The MPX 100 Delay, Echo variations include mono (5.5 seconds), stereo (2.7 seconds) and 6-voice multitap effects. Each of the 16 variations can be used for digital delay or tape echo effects. When **Adjust** is turned past its center position to the right, tape echo effects are produced. (Each repeat is darker and softer.) When Adjust is turned to the left of center, digital delay effects are produced. (Each repeat is the same timbre, but softer.)






In variations 1-8, **Adjust** also sets the amount of feedback — a single repeat when the knob is centered, more repeats as the knob is moved past center in either direction. Delay time is set with **Tap**. Each variation is preset with a different useful rhythm.

In Variations 9-16, the amount of feedback is preset and **Adjust** determines Delay time — the delay time is shortest when the knob is centered, increasing as the knob is moved away from center in either direction.

Delays and echoes are effects that repeat a sound a short time after it first occurs. The simplest (and oldest) delay effect is tape slap — a single repeat about 100ms after the original sound. (It was often used on Elvis’s voice and rockabilly guitar tracks.) Tape slap becomes tape echo when the output of the tape is fed back into the input (feedback), turning a single repeat into a series of repeats — each a little softer and a little darker than the last. This darkening of each repeat is characteristic of the analog tape recording process. Digital delays don’t have this characteristic — each repeat has the same exact timbre and the only difference from repeat to repeat is in loudness.

Digital delay and tape echo are both useful, but they are different. Tape echo is warmer and allows the original sound to stand out more, while digital delay can present a “perfect” copy of the original sound.

	Delay, Echo VARIATIONS	Adjust 	Tap 
1	Mono Quarter-Note	Delay/Echo Feedback	Delay Time
2	Stereo Quarter-Note	Delay/Echo Feedback	Delay Time
3	Triplet Shuffle	Delay/Echo Feedback	Delay Time
4	Dotted Eighth-Note	Delay/Echo Feedback	Delay Time
5	Eighth-Note and Triplet	Delay/Echo Feedback	Delay Time
6	Ping Pong Quarter-Note	Delay/Echo Feedback	Delay Time
7	Triplet Rhythm 1	Delay/Echo Feedback	Delay Time
8	Triplet Rhythm 2	Delay/Echo Feedback	Delay Time
9	Mono	Delay/Echo Time: 0-5.5sec	
10	Stereo	Delay/Echo Time: 0-2.7sec	
11	Tape Slap	Delay/Echo Time: 3 3/4 to 30ips	
12	Multi Bounce	Delay/Echo Time: 0-100ms	
13	Multi Linear	Delay/Echo Time: 0-400ms	
14	Multi Inverse	Delay/Echo Time: 0-400ms	
15	Multi Repeat	Delay/Echo Time: 0-150ms + Fbk	
16	Multi Pong	Delay/Echo Time: 0-200ms + Fbk	

When using any type of delay or echo effects with music, always pay attention to the way the repeats fall rhythmically to the beat. The most effective delay and echo patterns are those that lock in with the tempo of the tune.

About the Dual Programs

The MPX 100 Dual programs combine either a Delay or Reverb algorithm with a Flange, a Pitch or a Chorus. **Effects Lvl/Bal** controls the relative balance of each effect in the combination.


Four routing configurations are used in the variations of each Dual program: Dual Stereo (Parallel), Cascade, Mono Split and Dual Mono.

Variations 1-6 are set up in the Parallel configuration - two stereo effects placed side by side so that they receive and output stereo audio from both left and right channels.


Variations 7-10 are set up in the Cascade configuration - two stereo effects, one placed after the other (for example, Flange-Delay, Flange passes its stereo signal to the Delay).

Variations 11-14 are set up in the Mono Split configuration which is similar to Parallel, however one effect (Flange) receives audio from the left input and the other effect (Delay) receives audio from the right input. Both effects then output stereo audio.

Variations 15 and 16 are set up in the Dual Mono configuration where one effect (Flange) appears on the left channel only and the other effect (Delay) appears on the right channel only.









Generally, the **Effects Lvl/Bal** knob controls the balance of the two effects in each dual program. In the cascade variations, rather than simply controlling balance, the knob varies the amount of the first effect or dry signal which is fed into the second effect.










*Behavior of **Effects Lvl/Bal** in the cascade variations. Several points from the knob's continuous range are illustrated here, using the Pitch-Delay program as an example.*







Flange – Delay

	Flange-Delay VARIATIONS	Adjust 	Tap 	Routing
1	Deep Flange - Stereo Delay	Delay/Echo Feedback	Delay Time (1/4 Note)	
2	Deep Flange - Stereo Delay	Delay/Echo Feedback	Dotted 1/8 Note	
3	Deep Flange - Stereo Delay	Delay/Echo Feedback	1/8 Note Triplet	
4	Light Flange - Ping Pong	Delay/Echo Feedback	Delay Time (1/4 Note)	
5	Light Flange - Repeat	Delay/Echo Time: 0-150ms, Feedback	—	
6	Light Flange - Bounce	Delay/Echo Time: 0-200ms, Feedback	—	
7	Deep Flange>Stereo Delay	Delay/Echo Feedback	Delay Time (1/4 Note)	
8	Deep Flange>Repeat	Delay/Echo Time: 0-150ms, Feedback	—	
9	Deep Flange>Ping Pong	Delay/Echo Feedback	Delay Time (1/4 Note)	
10	Deep Flange> Bounce	Delay/Echo Time: 0-200ms, Feedback	—	
11	Light Flange+Stereo Delay	Delay/Echo Feedback	Delay Time (1/4 Note)	
12	Lighth Flange+Ping Pong	Delay/Echo Feedback	Delay Time (1/4 Note)	
13	Light Flange+Repeat	Delay/Echo Time: 0-150ms, Feedback	—	
14	Light Flange+Bounce	Delay/Echo Time: 0-200ms, Feedback	—	
15	Deep Flange/Mono Delay	Delay/Echo Feedback	Delay Time (1/4 Note)	
16	Deep Flange/Mono Delay	Delay/Echo Feedback	Delay Time (Dotted 1/4 Note)	








Pitch – Delay

	Pitch-Delay VARIATIONS	Adjust 	Tap 	Routing
1	5th Up/Down - Stereo Quarter-Note	± 5th	Delay Time	
2	Octave Up/Down - Triplet Shuffle	± 1 octave	Delay Time	
3	Octave Up/Down - Eighth and Triplet	± 1 octave	Delay Time	
4	3rd Up/4th Up - Ping Pong Quarter-Note	Minor 3rd to 4th Up	Delay Time	
5	4th Up/5th Up - Triplet Rhythm 1	4th to 5th Up	Delay Time	
6	5th Up/6th Up - Triplet Rhythm 2	5th to 6th Up	Delay Time	
7	Octave Up/Down > Triplet Rhythm 1	± 1 octave	Delay Time	
8	5th Up/Down > Triplet Rhythm 2	± 5th	Delay Time	
9	Major/Minor	Minor/Major 3rd w/Feedback	Delay Time	
10	Intervals Up	Ascending Intervals w/Feedback	Delay Time	
11	5th Up/Down + Stereo Quarter-Note	± 5th	Delay Time	
12	Octave Up/Down + Triplet Shuffle	± 1 octave	Delay Time	
13	4th Up/5th Up + Triplet Rhythm 1	4th to 5th Up	Delay Time	
14	5th Up/6th Up + Triplet Rhythm 2	5th to 6th Up	Delay Time	
15	Octave Up/Down / Mono Quarter-Note	± 1 octave	Delay Time	
16	Octave Up/Down / Triplet Shuffle	± 1 octave	Delay Time	










Chorus – Delay

	Chorus-Delay VARIATIONS	Adjust 	Tap 	Routing
1	Rich Chorus 1 - Stereo 1/4 Note	Delay/Echo Feedback	Delay Time	
2	Rich Chorus 1 - Dotted 1/8 Note	Delay/Echo Feedback	Delay Time	
3	Rich Chorus 1 - 1/8 Note and Triplet	Delay/Echo Feedback	Delay Time	
4	Rich Chorus 1 - Ping Pong 1/4 Note	Delay/Echo Feedback	Delay Time	
5	Rich Chorus 1 - Multi Repeat	Delay/Echo Time: 0-150ms, Feedback	—	
6	Rich Chorus 1 - Multi Pong	Delay/Echo Time: 0-200ms, Feedback	—	
7	Rich Chorus 1 - Stereo 1/4 Note	Delay/Echo Feedback	Delay Time	
8	Rich Chorus 2 - Multi Repeat	Delay/Echo Time: 0-150ms, Feedback	—	
9	Rich Chorus 2 - Ping Pong 1/4 Note	Delay/Echo Feedback	Delay Time	
10	Rich Chorus 3 - Multi Pong	Delay/Echo Time: 0-200ms, Feedback	—	
11	Rich Chorus 1 - Stereo 1/4 Note	Delay/Echo Feedback	Delay Time	
12	Rich Chorus 1 - Ping Pong 1/4 Note	Delay/Echo Feedback	Delay Time	
13	Rich Chorus 1 - Crossfeed	Delay/Echo Time: 0-150ms, Feedback	—	
14	Rich Chorus 1 - Multi Pong	Delay/Echo Time: 0-200ms, Feedback	—	
15	Rich Chorus 4 - Mono 1/4 Note	Delay/Echo Feedback	Delay Time	
16	Rich Chorus 4 - Dotted 1/8 Note	Delay/Echo Feedback	Delay Time	








Delay – Reverb

	Delay-Reverb VARIATIONS	Adjust 	Tap 	Routing
1	Stereo 1/4 Note - Small Space	Decay Time	Delay Time	
2	Triplet Shuffle - Medium Space	Decay Time	Delay Time	
3	1/8 Note and Triplet - Large Space	Decay Time	Delay Time	
4	Ping Pong 1/4 Note - Small Space	Decay Time	Delay Time	
5	Triplet Rhythm 1 - Medium Space	Decay Time	Delay Time	
6	Triplet Rhythm 2 - Large Space	Decay Time	Delay Time	
7	Stereo 1/4 Note > Room	Decay Time	Delay Time	
8	1/8 Note and Triplet > Large Space	Decay Time	Delay Time	
9	Triplet Rhythm 1 > Room	Decay Time	Delay Time	
10	Triplet Rhythm 2 > Large Space	Decay Time	Delay Time	
11	Stereo 1/4 Note + Medium Space	Decay Time	Delay Time	
12	Ping Pong 1/4 Note + Large Space	Decay Time	Delay Time	
13	Triplet Rhythm 1 + Medium Space	Decay Time	Delay Time	
14	Triplet Rhythm 2 + Small Space	Decay Time	Delay Time	
15	Mono 1/4 Note / Room	Decay Time	Delay Time	
16	Triplet Rhythm 2 / Large Space	Decay Time	Delay Time	








Flange – Reverb



	Flange-Reverb VARIATIONS	Adjust 	Tap 	Routing
1	Light Flange - Small Space	Decay	Flange Rate (Whole Note)	
2	Light Flange - Medium Space	Decay	Flange Rate (Whole Note)	
3	Light Flange - Large Space	Decay	Flange Rate (Whole Note)	
4	Deep Flange - Small Space	Decay	—	
5	Deep Flange - Medium Space	Decay	—	
6	Deep Flange - Large Space	Decay	—	
7	Light Flange > Large Space	Decay	Flange Rate (Whole Note)	
8	Deep Flange > Large Space	Decay	—	
9	Light Flange > Room	Liveness	Flange Rate (Whole Note)	
10	Deep Flange > Room	Liveness	—	
11	Light Flange + Medium Space	Decay	Flange Rate (Whole Note)	
12	Light Flange + Room	Liveness	Flange Rate (Whole Note)	
13	Deep Flange + Medium Space	Decay	—	
14	Deep Flange + Room	Liveness	—	
15	Light Flange / Large Space	Decay	Flange Rate (Whole Note)	
16	Light Flange / Large Space	Decay	Flange Rate (Whole Note)	

Pitch – Reverb

	Pitch-Reverb VARIATIONS	Adjust 	Tap 	Routing
1	Minor 3rd to 4th - Room	3rd to 4th Up	PreDelay (1/32 Note)	
2	4th to 5th - Room	4th to 5th Up	PreDelay (1/32 Note)	
3	5th to 6th - Room	5th to 6th Up	PreDelay (1/32 Note)	
4	±1 Octave - Medium Space	± 1 octave	PreDelay (1/32 Note)	
5	Power Chords - Medium Space	Decay Time	PreDelay (1/32 Note)	
6	Manual Detune - Room	Detuning	PreDelay (1/32 Note)	
7	±100 > Small Space	± 100 cents	PreDelay (1/32 Note)	
8	Power Chords - Large Space	Decay Time	PreDelay (1/32 Note)	
9	4ths > Medium Space	Decay Time	PreDelay (1/32 Note)	
10	Octaves > Medium Space	Decay Time	PreDelay (1/32 Note)	
11	4th to 5th + Room	4th to 5th Up	PreDelay (1/32 Note)	
12	5th to 6th + Room	5th to 6th Up	PreDelay (1/32 Note)	
13	4ths + Large Space	Decay Time	PreDelay (1/32 Note)	
14	Octaves + Medium Space	Decay Time	PreDelay (1/32 Note)	
15	Octaves / Medium Space	Decay Time	PreDelay (1/32 Note)	
16	4ths / Large Space	Decay Time	PreDelay (1/32 Note)	

Chorus – Reverb

	Chorus-Reverb VARIATIONS	Adjust 	Tap 	Routing
1	Rich Chorus 1 - Small Space	Decay Time	—	
2	Rich Chorus 1 - Medium Space	Decay Time	—	
3	Rich Chorus 1 - Large Space	Decay Time	—	
4	Rich Chorus 2 - Small Space	Decay Time	—	
5	Rich Chorus 2 - Medium Space	Decay Time	—	
6	Rich Chorus 2 - Large Space	Decay Time	—	
7	Rich Chorus 1 > Room	Liveness	—	
8	Rich Chorus 2 > Room	Liveness	—	
9	Rich Chorus 3 > Room	Liveness	—	
10	Rich Chorus 1 > Small Space	Decay Time	—	
11	Rich Chorus 1 + Small Space	Decay Time	—	
12	Rich Chorus 2 + Medium Space	Decay Time	—	
13	Rich Chorus 2 + Large Space	Decay Time	—	
14	Rich Chorus 1 + Large Space	Decay Time	—	
15	Rich Chorus 1 / Room	Liveness	—	
16	Rich Chorus 4 / Room	Liveness	—	

	Delay, Echo VARIATIONS	Adjust	Tap 
1	Infinite Reverb	High Cut	Echo
2	The Abyss	± Pitch Bend	–
3	Jet Flange	Tone	Rate (Whole Note)
4	Chorus Verb	High Cut	–
5	Rotary Delay	Dly/Echo Time: 0-150ms+Fbk	Rate (1/4 Note)
6	Fader Verb	Input Volume	Echo
7	PCM 60 - LgSize	Decay Time	–
8	LowRumble	Decay Time	–
9	Ducking Reverb	Decay Time	–
10	Ducking Chorus>Delay	± Resonance	–
11	Ducking Triplets	Delay/Echo Feedback	–
12	Subdividing Delay	Beat Value: 1/32-Whole Note	Delay Time
13	Panning Delays	Delay/Echo Feedback	Dly Time, Pan Rate
14	Dream Sequence	± Shift Amount	–
15	Infinite Repeat	Feedback: 0-Infinite	Dly Time (Whole Note)
16	Diffusor	Diffusion	–

Special FX

The Special FX variations showcase the flexibility and creative possibilities of the MPX 100. **Adjust** is completely different in each of the Variations, so be sure to experiment with all of them.

User Programs

When shipped from the factory, the sixteen MPX 100 User locations contain duplicates of the following programs:

User VARIATION	
1	Plate 2
2	Gate 9
3	Hall 5
4	Hall 6
5	Chamber 13
6	Ambience 3
7	Room 14
8	Tremolo 1
9	Rotary 9
10	Rotary 15
11	Chorus 3
12	Flange 12
13	Pitch 1
14	Detune 12
15	Delay, Echo 8
16	Delay, Echo 12

Reinitialization

Reinitializing the MPX 100 will reset all of the System Mode parameters to their factory defaults, replace any programs stored in the User bank with the factory-loaded preset copies, and clear any Learned patches. To do this:

1. Hold the **Store** button while powering up the MPX 100. (**Store** and **Tap** will flash rapidly.) Press **Tap** or **Bypass** to exit without reinitializing.
2. Press **Store** to reinitialize the MPX 100.


MIDI Operation

MPX 100 MIDI Behavior

The MPX 100 “learns” MIDI Channel, Program Change and Continuous Controllers in its Learn Mode.

As many as five Learn patches (for the front panel **Mix**, **Effects Lvl/Bal**, **Adjust**, **Bypass** and **Tap** controls) on as many as five MIDI Channels are supported.

Program Change messages 0-15 are reserved for executing program loads on any learned MIDI Channel — or a separate MIDI Channel can be selected for program load.



Assigning a MIDI Channel for Program Load

In order to use Program Change messages for Program loads as well as to control front panel buttons, the MPX 100 is designed to have one MIDI channel dedicated to loading programs. This is called the Program Load MIDI Channel.

Although this channel can be used to receive other Program Change messages, numbers 0-15 will always load the 16 variations of the currently loaded program. Program Change messages 0-15 will be ignored on all other MIDI Channels.

When shipped from the factory, the MPX 100 has MIDI Channel 1 assigned as the default Program Load channel. To re-define the Program Load assignment:

1. Simultaneously press **Store** and **Tap** to enter Learn Mode. (The **Store** LED flashes slowly and the **Tap** LED lights steadily to indicate Learn Mode is active.)



2. Send a Program Change message to the MPX 100. (The **Edit** LED will flash to show incoming MIDI activity.)
3. The MPX 100 learns the MIDI Channel of the transmitting device and re-assigns the Program Load function to that channel.
4. Simultaneously press **Store** and **Tap** to exit.

This Program Load channel assignment is remembered until it is deliberately re-set with the same procedure.

Using Program Change Messages for Program Load

The MPX 100 will allow loading of all of its 240 preset and 16 User programs via standard MIDI Program Change messages. It also conforms to the use of MIDI controller 32 to perform Bank Select, starting with the **User** bank as the first bank. (For the purposes of this discussion, each setting of the MPX 100 PROGRAM knob selects a “bank” of 16 programs.) The MPX 100 “banks” are ordered numerically from 0-15.

Here’s how it works. If a standard MIDI Program Change is sent to the MPX 100 on its Program Load MIDI Channel, Program Change messages 0-15 will load programs 1-16 from the current Program Bank.

If a Bank Select message (controller 32) precedes a Program Change message, any one of the 256 programs can be loaded.

For example, Program Change 1 with PROGRAM pointing to **Plate, Gate**, will cause the first Plate program to be loaded. Sending controller 32 with a value of 0, followed by Program Change 1, loads the first program of the **User** bank. Sending controller 32 with a value of 1, then Program Change 2, loads the second program in the **Flange-Delay** bank. Sending controller 32 with a value of 8, then program change 15 will load the last Gate program in the **Plate, Gate** bank.

Once a bank is selected, all subsequent Program Change messages will select programs within that bank until a new value for controller 32 is received, or until the PROGRAM or VARIATION knob is moved.

This function can be disabled with the MIDI Pgm Change parameter in System Mode.


MPX 100 Program Banks

0	User
1	Flange-Delay
2	Pitch-Delay
3	Chorus-Delay
4	Delay Reverb
5	Flange-Reverb
6	Pitch-Reverb
7	Chorus-Reverb
8	Plate, Gate
9	Hall, Chamber
10	Ambience, Room
11	Tremolo, Rotary
12	Chorus, Flange
13	Pitch, Detune
14	Delay, Echo
15	Special FX

Learning Continuous Controllers

The MPX 100 recognizes Pitch Bend, AfterTouch and MIDI Continuous Controllers 1-31 and 33-119. To Learn a Continuous Controller:

1. Simultaneously press **Store** and **Tap** to enter Learn Mode. (The **Store** LED flashes slowly and the **Tap** LED lights steadily to indicate Learn Mode is active.)



2. Move one of the MPX 100 front panel controls (**Mix**, **Effects Lvl/Bal**, **Adjust**, **Bypass** or **Tap**) to assign it to the controller.




3. Move the MIDI controller through its full range. To use only a fraction of the controller's range, limit your movement to the desired range.



The **Edit** LED will flash to indicate incoming MIDI activity.

4. Press **Store** to commit to the assignment. The **Store** LED will flash rapidly.



5. To assign another front panel control to a MIDI controller, repeat steps 2 - 5.
6. Simultaneously press **Store** and **Tap** to exit. The **Store** LED will flash rapidly if you have created or changed any assignments.

NOTE: When a MIDI controller is assigned to Bypass or Tap, moving it through the mid-point of its Learned range will execute a "press" of the front panel button.

Activating Bypass or Tap functions with Program Change Messages

The MPX 100 recognizes MIDI Program Changes 16-127 (17-128 on some MIDI devices) on any channel. To assign a Program Change message to **Bypass** or **Tap**:


1. Simultaneously press **Store** and **Tap** to enter Learn Mode. (The **Store** LED flashes slowly and the **Tap** LED lights steadily to indicate Learn Mode is active.)



2. Press the front panel button you want to control (**Bypass** or **Tap**).



3. Send a MIDI Program Change to the MPX 100. The **Edit** LED will flash to indicate incoming MIDI activity.
4. Press **Store** to commit to the assignment. The **Store** LED will flash rapidly.




5. Simultaneously press **Store** and **Tap** to exit. The **Store** LED will flash rapidly if you have created or changed any assignments.

To aid MIDI controllers (such as some foot controllers) which do not allow repeated Program Change messages to be sent by a single button, the MPX 100 learns the next highest Program Change along with every Program Change message it learns for **Bypass** and/or **Tap**. For example, if you Learn Program Change 20 as the source for Bypass, Program Change 21 will also control Bypass functions. To avoid conflicting **Bypass** and **Tap** assignments, leave a space between the two buttons' assignments. (i.e. if you learn Program Change 20 for **Bypass**, remember that 21 will also be learned, so you will have to jump to Program Change 22 (and 23) for **Tap**.)

Clearing a Learned Assignment


1. Simultaneously press **Store** and **Tap** to enter Learn Mode. (The **Store** LED flashes slowly and the **Tap** LED lights steadily to indicate Learn Mode is active.)



2. Move the front panel control that you want to clear (**Mix**, **Effects Lvl/Bal**, **Adjust**, **Bypass** or **Tap**).



3. Press **Store** to clear the assignment. The **Store** LED will flash rapidly.



4. To clear another front panel assignment, repeat steps 2 and 3.
5. Simultaneously press **Store** and **Tap** to exit. The **Store** LED will flash rapidly if you have changed any assignments.

Learnable Front Panel controls and Assignable MIDI Sources

Front Panel Control	MIDI Controllers 1-31, 33-119	MIDI Pgm Change 16-127*
Mix	Yes	No
Effects Lvl/Bal	Yes	No
Adjust	Yes	No
Bypass	Yes	Yes
Tap	Yes	Yes

*Program Change numbers 0-15 will be ignored except on the MIDI Channel assigned for program load.

MIDI Clock

The MPX 100 recognizes MIDI Clock messages and applies the tempo (40-400 BPM) to any program which utilizes the Tap-tempo feature. Connect a MIDI device which outputs MIDI Clock (such as the MPX R1 foot controller or a MIDI sequencer) to the MPX 100 MIDI IN jack, to have the MPX 100 automatically recognize and begin to process the MIDI clocks. When you change tempo on the connected device, the MPX 100 will follow along and adjust its delay times or rates to match the tempo.

This can be disabled with the MIDI Clock Receive parameter in System Mode.

MIDI Dumps

MIDI Dumps allow you to back up the 16 User programs, the currently running program, or your System Mode settings and Learned patch assignments, to a storage device (typically, a sequencer).

MIDI Dumps are performed in System Mode. To perform a dump of the User programs, the current program, or all of the System Mode parameter settings:

1. Press and hold **Bypass** for 2 seconds. The **Bypass** and **Store** LEDs will blink slowly to indicate you are in System Mode.
2. Turn VARIATION to:
 - 14 to dump the User programs
 - 15 to dump the current program
 - 16 to dump the System settings and Learned patch assignments
3. Press **Store** to execute the dump.
4. Press **Bypass** to exit System Mode.

MIDI Implementation

Lexicon MPX 100

Function		Transmitted	Recognized	Remarks
Basic Channel	Default Channel	X X	1 1-16	Learned
Mode	Default Messages Altered	X	Mode 2 X X	
Note Number	True Voice	X	X	
Velocity	Note ON Note OFF	X X	X (Off=9n v=0) X	
After Touch	Keys Channels	X X	X OX	used as controller Learned
Pitch Bender		X	OX	used as controller, Learned
Control Change		X	OX	1-119 (0 and 32 used as Bank Select) Learned

Program Change	True #	X	0-15=1-16	16-127 ignored; Program message 1-15=Program Change 1-16 for current Program Group
	Bank Select	X	O	
System Exclusive	Lexicon Real-Time non Real-Time	O X X	O X X	Product ID=14 (decimal) Device ID=MIDI Channel 0-15 = 1-16
System Common	:Song Pos :Song Sel :Tune	X X X	X X X	
System Real Time	:Clock :Commands	X X	O X	
Aux Messages	:Local ON/OFF :All Notes OFF :Active Sense :Reset	X X X	X X X	

Mode 1: OMNI ON, POLY Mode 2: OMNI ON, MONO
Mode 3: OMNI OFF, POLY Mode 4: OMNI OFF, MONO

O : Yes
X : No OX: Selectable

Specifications

Audio Inputs (2)

Level -30dBu to +4dBu
Impedance 500K unbalanced for Direct Instrument input (Unit detects a mono input on the right input)
1/4" connectors

Audio Outputs (2)

Level +8dBu typical
Impedance 75Ω for Headphone output (Right only used for mono output; Left only used for stereo headphones)
1/4" connectors

Digital Audio Output

20-bit Digital S/PDIF output (always active)
Sample Rate: 44.1kHz
Connector: Coaxial, RCA type

Footswitch

Tip/Ring/Sleeve phone jack for Bypass and Tap (optional)

Frequency Response

Wet/Dry: 20Hz-20kHz, ±1dB

THD+N

<0.05%, 20Hz-20kHz

Dynamic Range

A/A: >95dB typical, 20Hz-20kHz, unweighted
A/D: >100dB typical, 20Hz-20kHz, unweighted

Conversion

20 bits A/D, 20 bits D/A
44.1kHz sample rate

Crosstalk

>45dB

Internal Audio Data Path

DSP: 24-bit

Power Requirements

9VAC wall transformer provided

Dimensions

19"W x 1.75"H x 4"D (483 x 45 x 102mm)

Weight

Unit: 2 lbs, 2 oz (0.959kg)

Environment

Operating Temperature 32° to 104°F (0° to 40°C)
Relative Humidity 95% non-condensing

Specifications subject to change without notice.