



ProfilePanel RGBE



User Instructions

Profile Panel RGB™

Introduction

Unpacking: Thank you for purchasing the Profile Panel RGB™ by American DJ®. Every Profile Panel RGB™ has been thoroughly tested and has been shipped in perfect operating condition. Carefully check the shipping carton for damage that may have occurred during shipping. If the carton appears to be damaged, carefully inspect your fixture for any damage and be sure all accessories necessary to operate the unit has arrived intact. In the case damage has been found or parts are missing, please contact our toll free customer support number for further instructions. Do not return this unit to your dealer without first contacting customer support.

Introduction: The Profile Panel RGB™ is part of American DJ's continuing pursuit for creating high quality affordable intelligent fixtures. The Profile Panel RGB™ is a DMX intelligent LED stage panel/wash. This wash can be used in a stand alone mode or connected in a Master/Slave configuration. The unit can also be controlled via DMX controller. This wash has four operating modes: Sound Active mode, Program mode, RGB mode, and DMX control mode.

Customer Support: American DJ® provides a toll free customer support line, to provide set up help and to answer any question should you encounter problems during your set up or initial operation. You may also visit us on the web at www.americandj.com for any comments or suggestions. Service Hours are Monday through Friday 9:00 a.m. to 4:30 p.m. Pacific Standard Time.

Voice: (800) 322-6337

Fax: (323) 582-2941

E-mail: support@americandj.com

To purchase parts online visit <http://parts.americandj.com>

Warning! To prevent or reduce the risk of electrical shock or fire, do not expose this unit to rain or moisture.

Caution! There are no user serviceable parts inside this unit. Do not attempt any repairs yourself, doing so will void your manufactures warranty. In the unlikely event your unit may require service please contact American DJ®.

PLEASE recycle the shipping carton when ever possible.

Profile Panel RGB™

General Instructions

To optimize the performance of this product, please read these operating instructions carefully to familiarize yourself with the basic operations of this unit. These instructions contain important safety information regarding the use and maintenance of this unit. Please keep this manual with the unit, for future reference.

Profile Panel RGB™

Features

- 288 Ultra Bright LEDs
- Multi-Colors
- Color Strobe
- Electronic Dimming 0-100%
- Built in Microphone
- DMX-512 protocol
- 7 DMX Channel Modes: 2, 3, 4, 6, 7, 24, & 27 DMX Channels

Profile Panel RGB™

Warranty Registration

The Profile Panel RGB™ carries a 3 year (1095 days) limited warranty. Please fill out the enclosed warranty card to validate your purchase and warranty. You may also register your product online at www.americandj.com. All returned service items whether under warranty or not, must be freight pre-paid and accompany a return authorization (R.A.) number. If the unit is under warranty you must provide a copy of your proof of purchase invoice. Please contact American DJ® customer support for a R.A. number.

Profile Panel RGB™

Cleaning

Due to fog residue, smoke, and dust cleaning the internal and external optical lenses must be carried out periodically to optimize light output.

1. Use normal glass cleaner and a soft cloth to wipe down the outside casing.
2. Clean the external optics with glass cleaner and a soft cloth every 20 days.
3. Always be sure to dry all parts completely before plugging the unit back in.

Cleaning frequency depends on the environment in which the fixture operates (i.e. smoke, fog residue, dust, dew).

Profile Panel RGB™

Safety Precautions

- To reduce the risk of electrical shock or fire, do not expose this unit rain or moisture
- Do not spill water or other liquids into or on to your unit.
- Be sure that the local power outlet match that of the required voltage for your unit.
- Do not attempt to operate this unit if the power cord has been frayed or broken. Do not attempt to remove or break off the ground prong from the electrical cord. This prong is used to reduce the risk of electrical shock and fire in case of an internal short.
- Disconnect from main power before making any type of connection.
- Do not remove the cover under any conditions. There are no user serviceable parts inside.
- Never operate this unit when it's cover is removed.
- Never plug this unit in to a dimmer pack
- Always be sure to mount this unit in an area that will allow proper ventilation. Allow about 6" (15cm) between this device and a wall.
- Do not attempt to operate this unit, if it becomes damaged.
- This unit is intended for indoor use only, use of this product outdoors voids all warranties.
- During long periods of non-use, disconnect the unit's main power.
- Always mount this unit in safe and stable matter.
- Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to the point they exit from the unit.
- Cleaning -The fixture should be cleaned only as recommended by the manufacturer. See page 3 for cleaning details.
- Heat -The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
- The fixture should be serviced by qualified service personnel when:
 - A. The power-supply cord or the plug has been damaged.
 - B. Objects have fallen, or liquid has been spilled into the appliance.
 - C. The appliance has been exposed to rain or water.
 - D. The appliance does not appear to operate normally or exhibits a marked change in performance.

Power Supply: The American DJ® Profile Panel RGB™ contains an electronic ballast, which will auto sense the voltage when it is plugged into the power source. With the electronic ballast you do not need to worry about wall voltage, this unit can be plugged in anywhere. Also be sure to only use the included I.E.C. power cable supplied with the unit.

DMX-512: DMX is short for Digital Multiplex. This is a universal protocol used as a form of communication between intelligent fixtures and controllers. A DMX controller sends DMX data instructions from the controller to the fixture. DMX data is sent as serial data that travels from fixture to fixture via the DATA “IN” and DATA “OUT” XLR terminals located on all DMX fixtures (most controllers only have a DATA “OUT” terminal).

DMX Linking: DMX is a language allowing all makes and models of different manufactures to be linked together and operate from a single controller, as long as all fixtures and the controller are DMX compliant. To ensure proper DMX data transmission, when using several DMX fixtures try to use the shortest cable path possible. The order in which fixtures are connected in a DMX line does not influence the DMX addressing. For example; a fixture assigned a DMX address of 1 may be placed anywhere in a DMX line, at the beginning, at the end, or anywhere in the middle. When a fixture is assigned a DMX address of 1, the DMX controller knows to send DATA assigned to address 1 to that unit, no matter where it is located in the DMX chain.

Data Cable (DMX Cable) Requirements (For DMX Operation):

The Profile Panel RGB™ can be a 2, 3, 4, 6, 7, 24, or 27 channel DMX unit. The DMX address is set on the back panel of the Profile Panel RGB™. Your unit and your DMX controller require a approved DMX-512 110 Ohm Data cable for data input and data output (Figure 1). We recommend Accu-Cable DMX cables. If you are making your own cables, be sure to use standard 110-120 Ohm shielded cable (This cable may be purchased at almost all professional sound and lighting stores). Your cables should be made with a male and female XLR connector on either end of the cable. Also remember that DMX cable must be daisy chained and cannot be split.



Figure 1

Notice: Be sure to follow figures two and three when making your own cables. Do not use the ground lug on the XLR connector. Do not connect the cable’s shield conductor to the ground lug or allow the shield conductor to come in contact with the XLR’s outer casing. Grounding the shield could cause a short circuit and erratic behavior.




Figure 2




Figure 3

Special Note: Line Termination. When longer runs of cable are used, you may need to use a terminator on the last unit to avoid erratic behavior. A terminator is a 110-120 ohm 1/4 watt resistor which is connected between pins 2 and 3 of a male XLR connector (DATA + and DATA -). This unit is inserted in the female XLR connector of the last unit in your daisy chain to terminate the line. Using a cable terminator (ADJ part number Z-DMX/T) will decrease the possibilities of erratic behavior.



Termination reduces signal errors and avoids signal transmission problems and interference. It is always advisable to connect a DMX terminal, (Resistance 120 Ohm 1/4 W) between PIN 2 (DMX-) and PIN 3 (DMX +) of the last fixture.

Figure 4

5-Pin XLR DMX Connectors. Some manufactures use 5-pin DMX-512 data cables for DATA transmission in place of 3-pin. 5-pin DMX fixtures may be implemented in a 3-pin DMX line. When inserting standard 5-pin data cables in to a 3-pin line a cable adaptor must be used, these adaptors are readily available at most electric stores. The chart below details a proper cable conversion.

| Conductor | 3-Pin XLR Female (Out) | 5-Pin XLR Male (In) |
|----------------------------|------------------------|---------------------|
| Ground/Shield | Pin 1 | Pin 1 |
| Data Compliment (- signal) | Pin 2 | Pin 2 |
| Data True (+ signal) | Pin 3 | Pin 3 |
| Not Used | | Do Not Use |
| Not Used | | Do Not Use |

Operating Modes:

You can use the Profile Panel RGB™ in either a stand alone mode or a master/slave configuration, there are 5 modes to choose from:

- Program Mode - Choose a static color, color show, color fade show, or color cycle. The speed of the show is adjustable. You can also have the unit strobe in this mode.
- Sound-Active mode - The unit will react to sound, chasing through the built in programs.
- RGB mode - Choose one of the three colors to remain static or adjust the intensity of each color to make your desired color.
- Macro Mode - Choose 1 of 32 color macros.
- DMX control mode - This function will allow you to control each individual fixtures traits with a standard DMX 512 controller such as as the Elation® Show Designer™.

Master-Slave Operation:

This function will allows you to link units together to run in a Master-Slave mode. In Master-Slave operation one unit will act as the controlling unit and the others will react to the controlling units built-in programs. Any unit can act as a Master or as a Slave however, only one unit can be programmed to act as the “Master.”

Master-Slave Connections and Settings:

1. Daisy chain your units via the XLR connector on the rear of the unit. Use standard XLR microphone cables to link your units together. Remember that the Male XLR connector is the input and the Female XLR connector is the output. The first unit in the chain (master) will use the female XLR connector only. The last unit in the chain will use the male XLR connector only.
2. Using the Master unit, choose your desired mode or program and connect the “Slave” unit or units.
3. Set the “Slave” unit(s) to the DMX address mode. They will now follow the “Master” unit.

Program Mode & Sound Active Mode:

In Program Mode you can pick your desired factory installed program; static color, color show, color fade, or color cycle. You can apply a strobe effect to static colors, and control the speed of the color shows, color fade, and color cycle.

- A-01 - A-07 are static colors.
- A-08 - A-22 are color shows.
- A-23 is a color fade show.
- A-24 is a color cycle.

1. Plug the fixture in and press the MODE button until A-XX is displayed. You are now in AUTO mode.
2. Press the UP or DOWN buttons to find your desired effect.
3. If you have selected a static color, press the MODE button. F-XX should be displayed. Use the UP or DOWN buttons to adjust and select your desired Flash rate.
4. When you have chosen a color show (A-08 - A-23), press the MODE button to adjust the speed of the show. When you press the MODE button, the display will show “P-XX”. Press the UP or DOWN button to adjust and set the speed. When the display shows “P-So” your desired program is running in sound active mode. Sound active mode only applies to color shows A-08 - A-22, not to the color fade show (A-23).

NOTE: If you have a static color selected (A-01 - A-07), the Program speed (P-XX) menu will not display.

Macro Mode:

In this mode you can select 1 of 32 macros

1. Plug the fixture in and press the MODE button until either C-XX is displayed.
2. Press the UP or DOWN buttons to find your desired macro.

RGB Mode:

In this mode you can select either red, green, blue, or adjust the colors to make a desired color, which will remain static. Adjust the intensity of each color to make your desired color.

1. Plug the fixture in and press the MODE button until either “R”, “G”, or “B” is displayed.
2. Press the UP or DOWN buttons to adjust the intensity of the displayed color. When you have adjusted your desired color press MODE to scroll to the next color.

DMX Mode:

There are seven DMX Modes to choose from: 2 Channels, 3 Channels, 4 Channels, 6 Channels, 7 Channels, 24 Channels, or 27 Channels.

Operating through a DMX controller give the user the freedom to create their own programs tailored to their own individual needs.

1. This function will allow you to control each individual fixture's traits with a standard DMX 512 controller.
2. To run your fixture in DMX mode, plug in the fixture via the XLR connections to any standard DMX controller. Select your desired DMX mode, and then press the UP or DOWN buttons to adjust the DMX address.
3. To run the 2 Channel Mode, press the MODE button until "1000" is displayed. This is the DMX addressing for the 2 Channel Mode.
4. To run the 3 Channel Mode, press the MODE button until "2000" is displayed. This is the DMX addressing for the 3 Channel Mode.
5. To run the 4 Channel Mode, press the MODE button until "3000" is displayed. This is the DMX addressing for the 4 Channel Mode.
6. To run the 6 Channel Mode, press the MODE button until "4000" is displayed. This is the DMX addressing for the 6 Channel Mode.
7. To run the 7 Channel Mode, press the MODE button until "5000" is displayed. This is the DMX addressing for the 7 Channel Mode.
8. To run the 24 Channel Mode, press the MODE button until "6000" is displayed. This is the DMX addressing for the 24 Channel Mode.
9. To run the 27 Channel Mode, press the MODE button until "7000" is displayed. This is the DMX addressing for the 27 Channel Mode.
10. Please see pages 10-17 for DMX values and traits.

| Channel | Value | Function |
|----------------|--------------|-------------------------|
| 1 | 0 | COLOR MACROS OFF |
| | 1 - 7 | BASTARD AMBER |
| | 8 - 15 | MEDIUM AMBER |
| | 16 - 23 | PALE AMBER GOLD |
| | 24 - 31 | GALLO GOLD |
| | 32 - 39 | GOLDEN AMBER |
| | 40 - 47 | LIGHT RED |
| | 48 - 55 | MEDIUM RED |
| | 56 - 63 | MEDIUM PINK |
| | 64 - 71 | BROADWAY PINK |
| | 72 - 79 | FOLLIES PINK |
| | 80 - 87 | LIGHT LAVENDER |
| | 88 - 95 | SPECIAL LAVENDER |
| | 96 - 103 | LAVENDER |
| | 104 - 111 | INDIGO |
| | 112 - 119 | HEMSLEY BLUE |
| | 120 - 127 | TIPTON BLUE |
| | 128 - 135 | LIGHT STEEL BLUE |
| | 136 - 143 | LIGHT SKY BLUE |
| | 144 - 151 | SKY BLUE |
| | 152 - 159 | BRILLIANT BLUE |
| | 160 - 167 | LIGHT GREEN BLUE |
| | 168 - 175 | BRIGHT BLUE |
| | 176 - 183 | PRIMARY BLUE |
| | 184 - 191 | CONGO BLUE |
| | 192 - 199 | PALE YELLOW GREEN |
| | 200 - 207 | MOSS GREEN |
| | 208 - 215 | PRIMARY GREEN |
| | 216 - 223 | DOUBLE CTB |
| | 224 - 231 | FULL CTB |
| 232 - 239 | HALF CTB | |
| 240 - 247 | DARK BLUE | |
| 248 - 255 | WHITE | |
| 2 | 0 - 255 | MASTER DIMMER 0% - 100% |

| Profile Panel RGB™ | | 3 Channel Mode |
|--------------------|---------|--------------------|
| Channel | Value | Function |
| 1 | 1 - 255 | RED 0% - 100% |
| 2 | 1 - 255 | GREEN 0% - 100% |
| 3 | 1 - 255 | BLUE 0% - 100% |

| Profile Panel RGB™ | | DMX Values & Functions |
|--------------------|---------|-------------------------|
| Channel | Value | Function |
| 1 | 1 - 255 | RED 0% - 100% |
| 2 | 1 - 255 | GREEN 0% - 100% |
| 3 | 1 - 255 | BLUE 0% - 100% |
| 4 | 0 - 255 | MASTER DIMMER 0% - 100% |

| Profile Panel RGB™ | | DMX Values & Functions |
|--------------------|--------------------|--|
| Channel | Value | Function |
| 1 | 1 - 255 | RED 0% - 100% |
| 2 | 1 - 255 | GREEN 0% - 100% |
| 3 | 1 - 255 | BLUE 0% - 100% |
| 4 | 1 - 255 | COLOR MACROS (See Channel 1 under 2 Channel Mode) |
| 5 | 0 - 15 16 - 255 | STROBE OFF SLOW - FAST |
| 6 | 1 - 255 | MASTER DIMMER 0% - 100% |

| Profile Panel RGB™ | | 7 Channel Mode |
|--------------------|---|--|
| Channel | Value | Function |
| 1 | 1 - 255 | RED 0% - 100% |
| 2 | 1 - 255 | GREEN 0% - 100% |
| 3 | 1 - 255 | BLUE 0% - 100% |
| 4 | 1 - 255 | COLOR MACROS (See Channel 1 under 2 Channel Mode) |
| 5 | 0 - 15 16 - 255 | STROBE OFF SLOW - FAST |
| 6 | 0 - 79 80 - 89 90 - 99 100 - 109 110 - 119 120 - 129 130 - 139 140 - 149 150 - 159 160 - 169 170 - 179 180 - 189 190 - 199 200 - 209 210 - 219 220 - 229 230 - 239 240 - 255 | PROGRAMS OFF PROGRAM 1 PROGRAM 2 PROGRAM 3 PROGRAM 4 PROGRAM 5 PROGRAM 6 PROGRAM 7 PROGRAM 8 PROGRAM 9 PROGRAM 10 PROGRAM 11 PROGRAM 12 PROGRAM 13 PROGRAM 14 PROGRAM 15 PROGRAM 16 SOUND ACTIVE |
| 7 | 1 - 255 | MASTER DIMMER 0% - 100% |

| Profile Panel RGB™ | | 24 Channel Mode |
|--------------------|---------|----------------------|
| Channel | Value | Function |
| 1 | 1 - 255 | RED 1 0% - 100% |
| 2 | 1 - 255 | GREEN 1 0% - 100% |
| 3 | 1 - 255 | BLUE 1 0% - 100% |
| 4 | 1 - 255 | RED 2 0% - 100% |
| 5 | 1 - 255 | GREEN 2 0% - 100% |
| 6 | 1 - 255 | BLUE 2 0% - 100% |
| 7 | 1 - 255 | RED 3 0% - 100% |
| 8 | 1 - 255 | GREEN 3 0% - 100% |
| 9 | 1 - 255 | BLUE 3 0% - 100% |
| 10 | 1 - 255 | RED 4 0% - 100% |
| 11 | 1 - 255 | GREEN 4 0% - 100% |
| 12 | 1 - 255 | BLUE 4 0% - 100% |
| 13 | 1 - 255 | RED 5 0% - 100% |
| 14 | 1 - 255 | GREEN 5 0% - 100% |
| 15 | 1 - 255 | BLUE 5 0% - 100% |
| 16 | 1 - 255 | RED 6 0% - 100% |
| 17 | 1 - 255 | GREEN 6 0% - 100% |

| Profile Panel RGB™ | | 24 Channel Mode |
|--------------------|---------|----------------------|
| Channel | Value | Function |
| 18 | 1 - 255 | BLUE 6 0% - 100% |
| 19 | 1 - 255 | RED 7 0% - 100% |
| 20 | 1 - 255 | GREEN 7 0% - 100% |
| 21 | 1 - 255 | BLUE 7 0% - 100% |
| 22 | 1 - 255 | RED 8 0% - 100% |
| 23 | 1 - 255 | GREEN 8 0% - 100% |
| 24 | 1 - 255 | BLUE 8 0% - 100% |

| Profile Panel RGB™ | | 27 Channel Mode |
|--------------------|---------|----------------------|
| Channel | Value | Function |
| 1 | 1 - 255 | RED 1 0% - 100% |
| 2 | 1 - 255 | GREEN 1 0% - 100% |
| 3 | 1 - 255 | BLUE 1 0% - 100% |
| 4 | 1 - 255 | RED 2 0% - 100% |
| 5 | 1 - 255 | GREEN 2 0% - 100% |
| 6 | 1 - 255 | BLUE 2 0% - 100% |
| 7 | 1 - 255 | RED 3 0% - 100% |
| 8 | 1 - 255 | GREEN 3 0% - 100% |
| 9 | 1 - 255 | BLUE 3 0% - 100% |
| 10 | 1 - 255 | RED 4 0% - 100% |
| 11 | 1 - 255 | GREEN 4 0% - 100% |
| 12 | 1 - 255 | BLUE 4 0% - 100% |
| 13 | 1 - 255 | RED 5 0% - 100% |
| 14 | 1 - 255 | GREEN 5 0% - 100% |
| 15 | 1 - 255 | BLUE 5 0% - 100% |
| 16 | 1 - 255 | RED 6 0% - 100% |
| 17 | 1 - 255 | GREEN 6 0% - 100% |

| Profile Panel RGB™ | | 27 Channel Mode |
|--------------------|---|--|
| Channel | Value | Function |
| 18 | 1 - 255 | BLUE 6 0% - 100% |
| 19 | 1 - 255 | RED 7 0% - 100% |
| 20 | 1 - 255 | GREEN 7 0% - 100% |
| 21 | 1 - 255 | BLUE 7 0% - 100% |
| 22 | 1 - 255 | RED 8 0% - 100% |
| 23 | 1 - 255 | GREEN 8 0% - 100% |
| 24 | 1 - 255 | BLUE 8 0% - 100% |
| 25 | 0 - 15 16 - 255 | STROBE OFF SLOW - FAST |
| 26 | 0 - 79 80 - 89 90 - 99 100 - 109 110 - 119 120 - 129 130 - 139 140 - 149 150 - 159 160 - 169 170 - 179 180 - 189 190 - 199 200 - 209 210 - 219 220 - 229 | PROGRAMS OFF PROGRAM 1 PROGRAM 2 PROGRAM 3 PROGRAM 4 PROGRAM 5 PROGRAM 6 PROGRAM 7 PROGRAM 8 PROGRAM 9 PROGRAM 10 PROGRAM 11 PROGRAM 12 PROGRAM 13 PROGRAM 14 PROGRAM 15 |

| Profile Panel RGB™ | | 27 Channel Mode |
|--------------------|-----------|----------------------------|
| Channel | Value | Function |
| 26 | 220 - 229 | PROGRAM 15 |
| | 230 - 239 | PROGRAM 16 |
| | 240 - 255 | SOUND ACTIVE |
| 27 | 1 - 255 | MASTER DIMMER 0% - 100% |

Profile Panel RGB™ Fuse Replacement

Locate and remove the unit's power cord. Once the cord has been removed locate the fuse holder located inside the power socket. Insert a flat-head screw driver into the power socket and gently pry out the fuse holder. Remove the bad fuse and replace with a new one. The fuse holder has a built-in socket for a spare fuse be sure not to confuse the spare fuse with active fuse.

Profile Panel RGB™ Trouble Shooting

Listed below are a few common problems the user may encounter, with solutions.

Unit not responding to DMX:

1. Check that the DMX cables are connected properly and are wired correctly (pin 3 is "hot"; on some other DMX devices pin 2 may be 'hot'). Also, check that all cables are connected to the right connectors; it does matter which way the inputs and outputs are connected.
2. Some DMX modes have a dimmer channel. Make sure the dimmer channel is not at 0%

Unit does not respond to sound:

1. Quiet or high pitched sounds will not activate the unit.
2. Check the sound sensitivity level. See Sound Active mode.

*If problems are not resolved; Contact American DJ® for service.
1-800-322-6337*

Profile Panel RGB™ Warranty

MANUFACTURER'S LIMITED WARRANTY

A. American DJ, Inc. hereby warrants, to the original purchaser, American DJ and American Audio products to be free of manufacturing defects in material and workmanship for a prescribed period from the date of purchase (see specific warranty period on reverse). This warranty shall be valid only if the product is purchased within the United States of America, including possessions and territories. It is the owner's responsibility to establish the date and place of purchase by acceptable evidence, at the time service is sought.

B. For warranty service you must obtain a Return Authorization number (RA#) before sending back the product. Contact American DJ, Inc. Service Department at 800-322-6337. Send the product only to the American DJ, Inc. factory. All shipping charges must be pre-paid. If the requested repairs or service (including parts replacement) are within the terms of this warranty, American DJ, Inc. will pay return shipping charges only to a designated point within the United States. If the entire instrument is sent, it must be shipped in its original package. No accessories should be shipped with the product. If any accessories are shipped with the product, American DJ, Inc. shall have no liability whatsoever for loss of or damage to any such accessories, nor for the safe return thereof.

C. This warranty is void if the serial number has been altered or removed; if the product is modified in any manner which American DJ, Inc. concludes, after inspection, affects the reliability of the product; if the product has been repaired or serviced by anyone other than the American DJ, Inc. factory unless prior written authorization was issued to purchaser by American DJ, Inc.; if the product is damaged because not properly maintained as set forth in the instruction manual.

D. This is not a service contract, and this warranty does not include maintenance, cleaning or periodic check-up. During the period specified above, American DJ, Inc. will replace defective parts at its expense with new or refurbished parts, and will absorb all expenses for warranty service and repair labor by reason of defects in material or workmanship. The sole responsibility of American DJ, Inc. under this warranty shall be limited to the repair of the product, or replacement thereof, including parts, at the sole discretion of American DJ. All products covered by this warranty were manufactured after January 1, 1990, and bear identifying marks to that effect.

E. American DJ, Inc. reserves the right to make changes in design and/or improvements upon its products without any obligation to include these changes in any products theretofore manufactured. No warranty, whether expressed or implied, is given or made with respect to any accessory supplied with products described above. Except to the extent prohibited by applicable law, all implied warranties made by American DJ, Inc. in connection with this product, including warranties of merchantability or fitness, are limited in duration to the warranty period set forth above. And no warranties, whether expressed or implied, including warranties of merchantability or fitness, shall apply to this product after said period has expired. The consumer's and/or Dealer's sole remedy shall be such repair or replacement as is expressly provided above; and under no circumstances shall American DJ, Inc. be liable for any loss or damage, direct or consequential, arising out of the use of, or inability to use, this product.

This warranty is the only written warranty applicable to American DJ and American Audio Products and supersedes all prior warranties and written descriptions of warranty terms and conditions heretofore published.

MANUFACTURER'S LIMITED WARRANTY PERIODS:

- All American Audio Products = 1-year (365 day) Limited Warranty (except V-Plus Series Amplifiers)
- All American Audio V-Plus Series Amplifiers = 3-year (1095 day) Limited Warranty
- American DJ Lighting and American DJ Branded Products = 1-year (365 day) Limited Warranty (Such as: Special Effect Lighting, Intelligent Lighting, UV lighting, Strobes, Fog Machines, Bubble Machines, Mirror Balls, Par Cans, Trussing, Lighting Stands etc. excluding Laser Products, lamps, and Star Tec Series)
- American DJ Laser Products and Star Tec Products = 90-Day Limited Warranty
- American DJ L.E.D. Products = 3-year (1095 day) Limited Warranty (excluding motors which have a 1-year (365 day) Limited Warranty)

Model: Profile Panel RGB™SPECIFICATIONS:

| | |
|--------------------|---|
| Lamps: | 288 x 1W LEDs: 96 Red, 96 Green, and 96 Blue |
| Working Position: | Any safe working position |
| Voltage: | 100~240V 47Hz/63Hz “Auto Sensing” |
| Power Consumption: | 37W |
| Beam Angle: | 40 Degrees |
| Fuse: | 2 Amp |
| Weight: | 7lbs./ 2.9Kgs. |
| Dimensions: | 16.75” (L) x 9.5” (W) x 2” (H) 425 (L) x 240 (W) x 51.5 (H) mm |
| Colors: | RGB Color Mixing |
| DMX Channels: | 2, 3, 4, 6, 7, 24, & 27 |
| Warranty: | 3 Year (1095 days) |

Please Note: Specifications and improvements in the design of this unit and this manual are subject to change without any prior written notice.

Auto Sensing Voltage: *This fixture contains a electronic ballast, which will auto sense the voltage when it is plugged into the power source.*

©American DJ Supply
American DJ World Headquarters:
6122 S. Eastern Ave. Los Angeles, CA 90040 USA
Tel: 323-582-2650 / Fax: 323-582-2610
Web: www.americandj.com / E-mail: info@americandj.com

American DJ Europe
Junostraat 2
6468 EW Kerkrade
Netherlands
service@americandj.eu / www.americandj.eu
Tel: +31 45 546 85 00 / Fax: +31 45 546 85 99