



J. ROCKETT AUDIO DESIGNS


Controls

- Drive: Controls the level of grit and/or overdrive for the OD side and contributes to the grit/overdrive when cascaded with the boost side.
- Level: Controls the volume for the OD side and contributes to the volume control when cascaded with the boost side.
- Bass: Controls the bass and/or fatness of the OD side or contributes to the bass and/or fatness when cascaded with the boost side.
- Tone: Controls the brightness and/or presence of the OD side or contributes to the brightness and/or presence when cascaded with the boost side.
- > **P. Amp Switch**: Engages the "power amp" only or cascades it with the OD side.
- P. Amp Knob: Controls the volume of the boost or contributes to the output when cascaded with the OD side.
- > **On/Off**: Engages the pedal.

NOTE: The power amp section was created to emulate the 5881 servo tube found in the Naylor SD60. Even if you engage the "power amp" section at unity volume, it will add a certain amp-like fatness to your overall sound. You can also use it as a solo boost as well.

Power Supply

All J. Rockett Audio Designs pedals operate off of the standard BOSS type 9 volt adapter or a single 9 volt battery. The power input is a 5.5 mm x 2.1 mm jack with the positive voltage on the outer sleeve. Using an external power supply will automatically disconnect the battery. Disconnect the input jack to preserve battery life when not in use or when not used with an appropriate, external power supply.



2.1mm x 5.5 mm tip/negative plug

Warranty

J. Rockett Audio Designs LLC will repair or replace, at its discretion, defective workmanship or materials on all new J. Rockett Audio Designs products directly or through the selling dealer or an authorized service technician for one year from the date of purchase at no cost to the original purchaser. Repair and replacement parts installed will be warranted for the unexpired portion of the original warranty term.

Before sending a product in for repair, please contact us at <u>chris@rockettpedals.com</u> or <u>jay@rockettpedals.com</u> or call us at 760-419-1345.

This warranty does not cover shipping costs, product appearance or damages caused by accident, abuse, misuse or alteration. A dated sales slip or order number (issued by a tech, dealer or J. Rockett Audio Designs) must accompany a product being returned for warranty service. Repairs without a return authorization number will be refused. Please allow four (4) weeks for warranty service. For more information please contact J. Rockett Audio Designs via our website at <u>www.rockettpedals.com</u> or call us at 760-419-1345. No other warranty is expressed or implied.