

 Q CARD

# *Sanctuary*

INSTRUCTIONS  
and  
PROGRAM CHARTS

 ALESIS

The Sanctuary QCard contains 8 megabytes of new, high quality, 16 bit samples along with a bank of Programs that utilize them.

## Software Requirements:

This card will perform without incident in any revision of QS6™, QS7™, QS8™ and QSR™ as well as in the QuadraSynth™ Plus Piano and S4™ Plus Sound Module.

If you are using a QuadraSynth or S4 QuadraSynth Sound Module, you should use software version 1.07 or later in order to correctly play the Programs which you must load from the enclosed floppy disk. Earlier software versions may play the Programs differently than they were intended. If your unit has older software, please contact an authorized Alesis Service Center for a current software update. To display the software version of your unit, hold GLOBAL and press PROGRAM.

### Using the QCard Programs with QuadraSynth / S4 1.07 software:

To hear the new ROM CARD Programs on a QuadraSynth or S4 with 1.07 software, you must first load them into the USER bank from the enclosed floppy disk (both Macintosh and PC formats are provided) using a personal computer and a MIDI interface. Use the included Alesis FreeLoader™ application (or any other MIDI application that plays raw System Exclusive data) to load the bank. Open the FreeLoader application, configure your MIDI setup, Add the file named "Z3PRE107.SYX" to the Playlist and then press PLAY, which will load the bank into your QuadraSynth USER bank.

*IMPORTANT: Loading the new bank will erase the current USER bank in your QuadraSynth. For this reason, you should back up your current USER bank by saving it to a storage device (i.e., to a RAM card, or via SysEx dump to a MIDI librarian or sequencer) before loading the bank from the ROM CARD. The PC version of FreeLoader saves SysEx data as well as loads it, but the Macintosh version performs load functions only. For additional information on banks and storage conventions of the QuadraSynth, please consult your QuadraSynth Reference Manual.*

### Using the QCard Programs with a QuadraSynth Plus Piano, S4 Plus Sound Module, QS6, QS7, QS8 or QSR:

The QuadraSynth Plus Piano, S4 Plus Sound Module, QS6, QS7, QS8 and QSR can play Program and Mix data directly from the ROM CARD — you do not need to overwrite your USER bank in order to access your new ROM CARD Programs and Mixes.

To access ROM CARD Programs and Mixes, press [<BANK] or [BANK>] until the display reads "Crd1:" to the left of the Program or Mix name. You can then scroll through the ROM CARD Programs and Mixes in the same manner as you would with the PRESET or USER banks.

## Supplemental Program Banks:

The enclosed floppy disks contain two supplemental program banks designed for use ONLY in the QuadraSynth Plus Piano, S4 Plus, QS6, QS7, QS8 and QSR. These banks are NOT Compatible with a QuadraSynth or S4 Sound Module with 1.07 software. If one of the supplemental banks is accidentally loaded into a 1.07 QuadraSynth or S4, you should re-initialize your unit and then load a valid bank into your synth. Consult your reference manual for specific instructions on these procedures.

To play the supplemental program banks in the QuadraSynth Plus Piano, S4 Plus, QS6, QS7, QS8 and QSR, use included FreeLoader application to load the desired bank into the synth. Open the FreeLoader application, configure your MIDI setup, add the file to the Playlist and then press PLAY, which will load the bank into your QS USER bank.

With the ROM CARD inserted into the synth, any Alesis synthesizer Program can access the new card sounds. These new sounds are added to the list of sounds when accessing the VOICE function of Program Edit mode.

*NOTE: These sounds reside on the ROM CARD itself and are not loaded into the synth. This means that the ROM CARD must be inserted correctly in order to hear a Program with its intended ROM CARD sounds. If you recall such a Program and the ROM CARD is not inserted, nothing will be heard for voices assigned to a ROM CARD sound. On the other hand, if you insert a different ROM CARD and recall such a Program, those voices will use the sounds in the same location as the original ROM CARD's sounds.*

### To Assign a Program's Voice to a ROM CARD Sound on a QuadraSynth, S4, QuadraSynth Plus Piano or S4 Plus:

1. Press [PROGRAM] to put the QuadraSynth in Program mode, and select the Program to which you wish to assign a ROM CARD sound.
  2. Press [SELECT] to enter Program Edit mode. The display's edit status line will read: "EDITING: PROGRAM".
  3. Press [EDIT 1] to choose which of the four voices you wish to assign; the currently selected voice number (1-4) will appear to the right of the words "EDITING: PROGRAM".
  4. Press [ASSIGN] to jump to the ASSIGN VOICE page.
  5. Turn Quad Knob [1] to scroll past the internal Sound Groups to the ROM CARD's Sound Group. The upper display will show "Z3 Orgn.:" to indicate the group of sounds that reside on the ROM CARD.
- NOTE: If the ROM CARD is inserted improperly, you will not be able to access the new Sound Group.*
6. Turn Quad Knob [3] to select a ROM CARD sound. The name of the selected sound will appear to the right of the Sound Group name: **Z3 Orgn: Z3 Positiv** Use the [VALUE] buttons to select different card voices.

### To Assign a Program's Voice to a ROM CARD Sound on a QS6, QS7, QS8 or QSR:

1. Press [PROGRAM] to put the synth in Program mode, and select the Program to which you wish to assign a ROM CARD sound.
  2. Press [EDIT SELECT] to enter Program Edit mode, and then press [VOICE] (also labeled "40 BASS" on the button itself) to edit the Sounds used in the Program.
  3. Press [SOUND 1], [SOUND 2], [SOUND 3] or [SOUND 4] (also labeled "00 PIANO", "01 CHROMATIC", "02 ORGAN" and "03 GUITAR" respectively) to choose which of the four voices you wish to assign. NOTE: if the word "sound" is in lower case then this voice is not currently being used in the Program.
  4. Press [PAGE>] twice to jump to the SOUND GROUP SELECT page.
  5. Move the data entry slider to scroll past the internal Sound Groups to the ROM CARD's Sound Group. The display will show "Z3 Orgn.:" to indicate the first Sound Group that resides on the ROM CARD.
- NOTE: If the ROM CARD is inserted improperly, you will not be able to access the new Sound Group.*
6. Press [PAGE>] once more to select the individual Sound within the Sound Group. The display will read: **SOUND: Z3 Positiv** Use the [VALUE] buttons to select different card voices.

### Handling and Precautions:

- Keep the ROM CARD away from direct sunlight and moisture.
- Never poke anything into the pin slots of the ROM CARD.
- Keep the ROM CARD edge free from contaminants which can jam into the receiving pins and prevent good contact.
- Do not force the ROM CARD into the Sound Card slot — be sure it is aligned properly before pushing it in.
- Keep the ROM CARD in its protective case when not in use.

# SANCTUARY

#	NAME	TYPE	#	NAME	TYPE
0	Sanctuary	Special	32	HarpsiDark	Chromatic
1	Pipes&Brs	Special	33	Harpsilute	Chromatic
2	Firmament	Special	34	Jerusalem	Chromatic
3	Glorious!	Special	35	Aruba	Chromatic
4	Bell Choir	Special	36	CelestDrum	Chromatic
5	Tines&Aahs	Special	37	Music Box	Chromatic
6	EPno Oohs	Special	38	Class Harp	Chromatic
7	SweetSwell	Special	39	Anna Harp	Chromatic
8	ModrnPrayr	Special	40	Velo Bells	Bells
9	Harpsi&Pad	Special	41	MutedBells	Bells
10	Principale	Pipe Organ	42	Loose Bell	Bells
11	Positiv	Pipe Organ	43	Sweet Bell	Bells
12	Trompette	Pipe Organ	44	Tubular	Bells
13	Scharf	Pipe Organ	45	Clock Bell	Bells
14	Reed	Pipe Organ	46	Break Drum	Bells
15	Processnal	Pipe Organ	47	IceCeleste	Bells
16	SlidrStops	Pipe Organ	48	Crotales	Bells
17	Mid Pipes	Pipe Organ	49	Chime Tree	Bells
18	St. Mark's	Pipe Organ	50	SlideBells	Synth Bells
19	St. Paul's	Pipe Organ	51	SpaceBell1	Synth Bells
20	Tonewheel	Electric Organ	52	SpaceBell2	Synth Bells
21	Contempary	Electric Organ	53	Kybd Bell	Synth Bells
22	GospelMWhl	Electric Organ	54	Tinklette	Synth Bells
23	Promenade	Electric Organ	55	PressurBel	Synth Bells
24	Prelude	Electric Organ	56	Celesteal	Synth Bells
25	HybridTWhl	Electric Organ	57	Conic	Synth Bells
26	Wave Organ	Electric Organ	58	Desert Sun	Synth Bells
27	ModernPipe	Electric Organ	59	Legato Hvn	Synth Bells
28	Celombete	Electric Organ	60	AcoustcBas	Bass
29	GlassOrgan	Electric Organ	61	FretlessBs	Bass
30	Harpsichrd	Chromatic	62	Home Bass	Bass
31	Harpsi8'4'	Chromatic	63	SoftElBass	Bass

# 128 PROGRAMS

#	NAME	TYPE	#	NAME	TYPE
64	CranialBas	Bass	96	Glory Horn	Orchestral
65	AKA SynBss	Bass	97	Herald	Orchestral
66	AKA SqrBss	Bass	98	Orchestra1	Orchestral
67	ClassicSaw	Bass	99	Orchestra2	Orchestral
68	ElecOrgPdl	Bass	100	Choir Ahh	Voices
69	PipeOrgPdl	Bass	101	Clascl Ahh	Voices
70	CrystalEP1	Electric Piano	102	EnsmbleOoh	Voices
71	CrystalEP2	Electric Piano	103	Chorus Ooh	Voices
72	CrystalEP3	Electric Piano	104	Hummmm	Voices
73	CrystalEP4	Electric Piano	105	Boys'Choir	Voices
74	'LectPiano	Electric Piano	106	Young&Old	Voices
75	Star E Pno	Electric Piano	107	Solo Voice	Voices
76	Bell E Pno	Electric Piano	108	Amen VelSw	Voices
77	Dark EP 1	Electric Piano	109	Amen Split	Voices
78	Dark EP 2	Electric Piano	110	VelOoz&Aaz	Synth Voices
79	ReflectvEP	Electric Piano	111	His & Hers	Synth Voices
80	Peaceful	Synth	112	Slow Ahhs	Synth Voices
81	Zephyr Pad	Synth	113	Slow Oohs	Synth Voices
82	Modrn Tri	Synth	114	RivrJordan	Synth Voices
83	Air Pad	Synth	115	MiracleVox	Synth Voices
84	String Pad	Synth	116	Gethsemane	Synth Voices
85	Anastring	Synth	117	Bell&Voice	Synth Voices
86	Cloud Nine	Synth	118	Harps&Oohs	Synth Voices
87	AngelWings	Synth	119	Vox Humana	Synth Voices
88	DynamicPad	Synth	120	Storm	Effects
89	OB Brass	Synth	121	Jericho	Effects
90	Flute Vib	Orchestral	122	The Wind	Effects
91	Vel Chuffs	Orchestral	123	The Rain	Effects
92	Recorder	Orchestral	124	The Flood	Effects
93	Trumpet	Orchestral	125	Crickets	Effects
94	Cornet	Orchestral	126	Windchimes	Effects
95	Trombones	Orchestral	127	ZimblStern	Effects

# SANCTUARY

#	NAME	TYPE	#	NAME	TYPE
0	The Works	Special	26	Tonewl&Pdl	Organ/Bass splits
1	Jubilant	Special	27	Contmp&Pdl	Organ/Bass splits
2	GrndEntrnc	Special	28	ContmpSplT	Organ/Bass splits
3	GiantChrch	Special	29	EOrgn&Bass	Organ/Bass splits
4	LookingGls	Special	30	Harpsibell	Chromatic layers/splits
5	PraiseLayr	Special	31	Nice Bells	Chromatic layers/splits
6	Manna	Special	32	Bright Key	Chromatic layers/splits
7	More Five	Special	33	MoodEharp	Chromatic layers/splits
8	ChymMotion	Special	34	WoodyBells	Chromatic layers/splits
9	ModrnSplit	Special	35	HrpsiPdSpl	Chromatic layers/splits
10	CathedralA	Organ Layers	36	HrpsiFltBs	Chromatic layers/splits
11	CathedralB	Organ Layers	37	HrpPad&Bas	Chromatic layers/splits
12	Deep Pipes	Organ Layers	38	Harpsivox	Chromatic layers/splits
13	Hall Pipes	Organ Layers	39	Harp&Synth	Chromatic layers/splits
14	BrightPipe	Organ Layers	40	Gorgeous	Bell layers
15	Circa Sol	Organ Layers	41	PraisePipe	Bell layers
16	WarmChurch	Organ Layers	42	More Huge	Bell layers
17	Lightness	Organ Layers	43	Bells Sing	Bell layers
18	StainGlass	Organ Layers	44	Pure Bells	Bell layers
19	SlidrPipes	Organ Layers	45	Shimmerz	Bell layers
20	StPaul&Pdl	Organ/Bass splits	46	HPF Bells	Bell layers
21	StMark&Pdl	Organ/Bass splits	47	HrdCrotale	Bell layers
22	SliderSplT	Organ/Bass splits	48	In Bellfry	Bell layers
23	Deep&Brite	Organ/Bass splits	49	Delicata	Bell layers
24	Pipes&Bass	Organ/Bass splits	50	Contempltn	Electric Piano layers/splits
25	Procsn&Pdl	Organ/Bass splits	51	CrystalBed	Electric Piano layers/splits

#	NAME	TYPE	#	NAME	TYPE
52	ModernKeys	Electric Piano layers/splits	78	GentleFlow	Voice layers
53	Eep Design	Electric Piano layers/splits	79	Icy Night	Voice layers
54	SeashorPno	Electric Piano layers/splits	80	Clear Sky	Synth 1
55	Bass&EPno1	Electric Piano layers/splits	81	Star2Guide	Synth 1
56	Bass&EPno2	Electric Piano layers/splits	82	Celestious	Synth 1
57	Bass&EPno3	Electric Piano layers/splits	83	DesrtAngel	Synth 1
58	Bass&EPno4	Electric Piano layers/splits	84	Conicopia	Synth 1
59	Bass&EPno5	Electric Piano layers/splits	85	Tri Pad	Synth 1
60	Pastures	Orchestral layers/splits	86	Swells	Synth 1
61	ShephrdEns	Orchestral layers/splits	87	Night Sky	Synth 1
62	Lilt Brass	Orchestral layers/splits	88	Bell Life	Synth 1
63	BriteBrass	Orchestral layers/splits	89	Semibrass	Synth 1
64	Trmps&Tbns	Orchestral layers/splits	90	SkyIsOpen	Synth 2
65	GlorySplit	Orchestral layers/splits	91	TombsEmpty	Synth 2
66	Big Split	Orchestral layers/splits	92	Intervalis	Synth 2
67	AmbiFlutes	Orchestral layers/splits	93	EarthShakr	Synth 2
68	LH/RHSplit	Orchestral layers/splits	94	Alive	Synth 2
69	NightFlute	Orchestral layers/splits	95	Windarr!	Synth 2
70	StereoAhhs	Voice layers	96	SingInRain	Synth 2
71	StereoOohs	Voice layers	97	Moodella	Synth 2
72	Two Choirs	Voice layers	98	Aqua	Synth 2
73	Hummingpad	Voice layers	99	Porch	Synth 2
74	Blendarr!	Voice layers	<p><i>Autodemo 1: O Holy Night - composed by Adolphe Adam. Arranged and performed by David Bryce.</i></p> <p><i>Autodemo 2: Amen Selections - composed and arranged by John P. Lotze. Additional arrangement by Randy Lee.</i></p> <p>To play the autodemos, hold MIX and then press "00 PIANO" followed by "0" for autodemo 1, or "00 PIANO" followed by "1" for autodemo 2. To stop the autodemo, press PRDGRAM or MIX.</p> <p>To access the autodemos using synthesizers with multiple card slots, the QCard must be inserted in slot A.</p> <p><i>Note: The QuadraSynth, S4, QuadraSynth Plus Piano and S4 Plus do not support the QCard autodemo function.</i></p>		
75	Moving Vox	Voice layers			
76	Big Air	Voice layers			
77	Harp Vox	Voice layers			

# SOUND INDEX

Here is a list of the new sounds on this ROM CARD. These sounds reside in several Sound Groups listed below.

KYBD GROUP	SOUND
<b>Z3Orgn</b>	Z3 Positiv, Z3Prncpal, Trompette, Scharf, Full Pipes, Pipe Chiff, TonewhlOrg, Drawbars, OrganWave1, OrganWave2, OrganWave3, OrganWave4, OrganWave5
<b>Z3Chrm</b>	FM Tines, Soft Tines, VelAtkTine, EP Wave 1, EP Wave 2, EP Wave 3, EP Wave 4, EP Wave 5, EP Wave 6, Z3 Harpsi, Z3HrpsiWv, HarpsiAttk, GlasCelest, Fantastic, FantstcWav, Ice Block, Handbell 1, Handbell 2, Carillon, Jerus Harp, Tublr Bell
<b>Z3Bass</b>	AcoustBass , Fretless, FretlsTone
<b>Z3 Vox</b>	Choir Ahh, Male Ahh, FemaleAhh, Choir Meh, Choir Nnnn, ClassclAhh, EnsmbleAhh, Ensmbl Ooh, Chorus Ooh, Boys Choir, Solo Voice



**KYBD  
GROUP****SOUND**

- Z3Orch** C Trumpet, Bb Trumpet, Flute Vibr, FluteNoVib, Flute Air,  
Recorder, Z3 Harp
- Z3Wave** Sine, Sawtooth, Square, Triangle, Additive, Inharmonic1,  
Inharmonic2, Analog Pad
- Z3 FX** WindChimes, Zimblstern, Rain, ResWind, Crickets

ALESIS CORPORATION ("ALESIS") warrants this product to be free of defects in material and workmanship for a period of 90 days from the date of original retail purchase. This warranty is enforceable only by the original retail purchaser.

During the warranty period ALESIS shall, at its sole and absolute option, either repair or replace free of charge any product that proves to be defective on inspection by ALESIS or its authorized service representative. In all cases disputes concerning this warranty shall be resolved as prescribed by law.

To obtain warranty service, the purchaser must first call or write ALESIS at the address and telephone number printed below to obtain a Return Authorization Number and instructions concerning where to return the unit for service. All inquiries must be accompanied by a description of the problem. All authorized returns must be sent to ALESIS or an authorized ALESIS repair facility postage prepaid, insured and properly packaged. Proof of purchase must be presented in the form of a bill of sale, canceled check or some other positive proof that the product is within the warranty period. ALESIS reserves the right to update any unit returned for repair. ALESIS reserves the right to change or improve design of the product at any time without prior notice.

This warranty does not cover claims for damage due to abuse, neglect, alteration, adjustment, modification or attempted repair by unauthorized personnel, and is limited to failures arising during normal use that are due to defects in material or workmanship in the product. This warranty also does not cover loss or damage which occurs in shipment or which is due to improper installation or maintenance, misuse or any cause (including without limitation accidents or acts of God) other than ordinary applications; or improper environment or excessive or inadequate heating or air conditioning or electrical power failures, surges or other irregularities. This warranty also does not cover any battery for the product, and Alesis is not liable for data, which is stored or is to be stored by the product and which is erased or otherwise impaired by any cause whatsoever. Alesis' liability for damages for any cause whatsoever, regardless of the form of action and whether in contract or in tort, shall be limited to the purchase price in effect when the cause of action that is the basis of the claim arose for the product.

ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE LENGTH OF THIS LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

IN NO EVENT WILL ALESIS BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR OTHER DAMAGES RESULTING FROM THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING, AMONG OTHER THINGS, DAMAGE TO PROPERTY, DAMAGE BASED ON INCONVENIENCE OR ON LOSS OF USE OF THE PRODUCT, AND, TO THE EXTENT PERMITTED BY LAW, DAMAGES FOR PERSONAL INJURY. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

This warranty only applies to products sold in the United States of America or Canada. The terms of this warranty and any obligations of Alesis under this warranty shall apply only within the country of sale. Without limiting the foregoing, repairs under this warranty shall be made only by a duly authorized Alesis service representative in the country of sale. For warranty information in all other countries please refer to your local distributor.

All Trademarks are Property of Their Respective Holders.

©1996 Alesis Corporation Specifications Subject To Change Without Notice

Printed in USA 7-51-1187

**ALESIS**