



www.WamplerPedals.com

Pinnacle Manual

Thank you for purchasing the Wampler Pedals Pinnacle Overdrive/Distortion Pedal. This short guide will explain how the pedal works and how to get the optimum sound with the pedal through your equipment.

Depending on the model you purchased, there are four knobs on this pedal, a footswitch (for on/off) and two toggle switches, **or** one toggle switch and two footswitches (one for on/off, one for boost). On the two-toggle model, one toggle boosts high frequencies and the other toggle adds a gain boost. The two-foot switch model has the gain boost on the foot switch, letting you kick it in live without having to bend over. On both models, the bright switch is great for adding some real cut to amps that aren't crispy clear in the high end, such as any of the darker Marshalls or Mesa Boogie amps. It might be too bright on amps that have a lot of treble already, so just adjust to taste.

There is a "drive" knob which controls the amount of overdrive or distortion; a sophisticated "contour" knob which gives you many EQ options – turn it all the way clockwise to remove much of the mid frequencies, or to about 50% for a very rounded warm midrange, and at 25% or lower it will add a lot of midrange and make it as warm as possible. This control is interactive with the bright switch: lots of tonal territory to explore!

The tone control will remove highs for a silky smooth tone. The volume control adjusts the output level.

The pedal basically emulates the way a tube compresses and clips the guitar signal. A huge range of tones are available, so have fun getting to know one of our favorite pedals, and one which customers often complement as having the ability to get an authentic "brown" distortion tone with clarity and punch galore.

If using a power supply, power needed for the pedal is 9vdc center pin negative, just like most standard Boss™/Ibanez™/Etc type pedals. My favorite is the Visual Sound One spot™.

There is a battery connection inside, if you would like to use it you will need to open the bottom plate and insert a battery.

Warranties

There is a 7-day "no questions asked" period where you may return the pedal if you do not like the sound of it. You will need to pay for shipping to us, however, and if anything is damaged or broken (except for malfunction or premature wear) we will have to deduct that from the refund. The 7 days start upon receipt of pedal. This is not valid if purchasing through a dealer however. In this instance, ask the dealer for their warranty policy should you wish to return it.

The warranty period on this pedal is 5 years parts and labor (except due to abuse), and becomes valid only AFTER you register your pedal with us at http://www.wamplerpedals.com/warranty_registration

For warranty repairs on these pedals, please contact us at http://www.wamplerpedals.com/contact_us.html