

CAUTION! Please read and understand these instructions before installing or operating this unit.

SPECIFICATIONS:

Model: E 109

Lamp: 2 x LL-64514 120V 300W

Weight: 7 lbs

Size: 14" x 12" x 12"W

Fuse: 10 Amp Supply Voltage: 120V

Working Position: Any Safe position

Duty Cycle: 10 min. on,10 min. off

Colors: Multiple Colored Lenses

Warranty: 90 Days

Operating Instructions:

The E 109 is a powerful effect for clubs and dj's. The E 109 creates a dramatic cluster of 30 multi-colored beams. This unit features an internal microphone that allows the beams to be triggered by sound. The E 109's beams bounce up and down to the beat of the music. The E 109 is ready to be hung or set on the ground in a safe position. When mounting this unit to truss be sure to use a clamp. Plug the unit in to a standard 110 wall outlet. After plugging the unit in, the fixture will react to the beat of the music via the sound active internal microphone. The unit has a sensitivity knob on the rear of the unit that makes more or less sensitive to sound. Turing the knob in clockwise direction will make the unit more sensitive to sound. The unit requires sound to activate the movement.

Lamp Replacement: Disconnect the units main power supply. Unscrew and remove the thumb screws on the front of the fixture. Remove and replace the bulbs. Reassemble and reconnect the power supply. Be sure to follow all the handling instruction that are included with your new lamp.

Caution! Never open unit when in use. Always disconnect main power before serving or replacing lamp. Remember to always replace with the exact same type lamp and fuse.

HALOGEN LAMP WARNING!

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.