



# EUROLIGHT LC2412 Overview sheet (Front)


1 A Preset section




5 Programming section



2 B Memory section



3 Sound to light section




4 Flash keys

6 Main section


7 Chase section

# MENU STRUCTURE OVERVIEW


Setup functions/System check (start with Soft A + Soft B + Flash 1, turn data wheel to proceed)




## Programming Memories




## Programming Chases




## Modifying Memories




## Modifying CTM




## Chase to memory



## DMX512 Softpatch



## Disable Solo/Select Curve



# EUROLIGHT LC2412 Overview sheet (Rear)

