

# STROBO+PLUS HD™

## QUICK START INSTRUCTIONS FOR YOUR STROBOPLUS HD™ PLEASE READ!

Your StroboPlus HD™ is firmware upgradable so it is **VERY IMPORTANT** that you register this product on our PetersonConnect™ website which will then check for firmware updates and install them for you. Please go to [www.PetersonTuners.com/connect](http://www.PetersonTuners.com/connect) and plug your StroboPlus into your computer using the supplied USB cable. The website will instruct you how to register and update.



**To turn your StroboPlus on and off**, press and hold the power button for two seconds. It will start in the StroboTuner mode ready for you to begin tuning to equal temperament.

**If you want to change to Audio Mode**, press the mode button until you see strobe patterns only on the far left and far right side. To hear the pitch, press the start button.

**To charge the Lithium-Ion battery**, plug your StroboPlus into the USB connection of any computer or common USB 5 Volt charger of the type used by many phones and other devices.

**The StroboPlus display** features two strobe bands. Underneath the strobe screen, the note name is displayed as a large letter along with the octave from which it is derived, which is displayed as a number. To tune, carefully adjust the tuning of your instrument until the display appears stopped or “caged“. If the note you are tuning is too sharp, the bars will drift to the right; if flat, they will move to the left.

**If you are new to strobe tuners**, you will notice that they are much more sensitive and accurate than your previous tuner. If you are tuning a stringed instrument, you will need to adjust your “touch“ when you pluck a string to tune. Initially, instead of a plectrum, use your finger or thumb to gently pluck the string or simply reduce the volume of your instrument until you become accustomed to tuning accurately.

**Peterson BodyBeat™ metronome features** can be installed in your StrobePlus as an optional upgrade on our PetersonConnect website. This will enable all of the advanced metronome features of the BodyBeat with the exception of wireless synchronization. A vibe clip from any BodyBeat metronome can be used with the StrobePlus or a vibe clip can be purchased when upgrading.

If you experience any problems please **do not return the product to the store** that you purchased it from. First look at the helpdesk and FAQ at [www.PetersonTuners.com](http://www.PetersonTuners.com). If you continue to have problems, please open a helpdesk ticket or contact Peterson at 1-708-388-3311. We guarantee your full satisfaction with this and all Peterson products!

