AmpRidge	MightyMic W User Manual	MightyMic W User Manual	MightyMic W User Manual	
AmpRidge	1. Introduction	3. Connection Diagram	Desired Result Required Action	
HightyMic W iPhone Bluetooth & Wireless Microphone User Manual	 Thank you for choosing the MightyMic W Bluetooth microphone. In order to use the MightyMic W as a wireless Microphone you will need to use either the Movie/Pro App for video recording or other voice recording Apps for audio recording. Please visit our website for the latest info on Apps and features. The MightyMic W will also work as a Bluetooth Headset or as a playback device. These functions are also listed in this manual. Safety Rules To ensure your safety before using the Bluetooth Microphone please carefully read through this user manual. Be wary of any sharp edges, uneven surfaces, metal parts, accessories and their packaging so as to prevent any possible injuries to you or damages to the microphone. Do not modify, repair or dismatite this Bluetooth microphone. Deing so may result in fire, electric shocks, complete failure of this Bluetooth Device, etc. All of which, are not covered under the warranty. Do not use the Bluetooth Microphone in a hazardous location. 2. Package includes 	Charging/3.5mm Earphone Jack Volume up Button	Volume up Button Press the *+* button to increase the playback volume Volume down Press the *-* button to decrease the playback volume Low battery The Ded I FOWN flash	
		Power On/ Pairing/ Multi-Function Button 4. How to use 4.1. General Functions Desired Result Required Action	warning Plug the charger into the to jack on the MightyMic W.	
			Battery power indication Battery status will be shown on the top right corner of the phone screen after connected. (Only on iPhone, iPad Devices)	
			Factory reset At the same time press the "O" and "-" button for 5 seconds during the pairing mode to clear the paired device list	
		Turn on Press the "O" button for 3 seconds when the device is off. (Pink LED slowly flashes)	Note: Please download the latest updated manual at ampridge.com	
		Enter the pairing When the device is off, Press the "O" button for 10 seconds, (The Blue LED and Red LED will quickly flash alternately).		
	1 Wireless Microphone 1 USB Charger cable 1 Carrying Bag 1 User Manual	In pairing Mode use a Bluetooth compatible iPhone, iPad, or other Bluetooth IOS Device to perform the pairing action (For more details refer to the chapter about pairing)		
		Turn Off Press the " Or button for 5 seconds when the device is on.(All LED will be off)		
	1	2	3	

MightyMic W User Manual	MightyMic W User Manual		MightyMic W User Manual	MightyMic W User Manual
MightyMic W Oser Manual	Mightymic W Oser Manual	Mightymic w Oser Mahuai		
4.2 Pairing to an iPhone or iPad device	4.4 Using the MightyMic W Microphone	5. Warranty/Product Information		8. FAQ
To use your Bluetooth Microphone, you must first pair it with a device. Once your Bluetooth Microphone is paired to a specific device, they will remain paired and automatically recognize each other whenever they are within range. Pairing instructions: • Turn on your IPhone and ensure the Bluetooth function	 Make sure the MightyMic W is already paired to your phone or other IOS device. See Section 4.2 for instructions. Make sure your phone is set to airplane mode otherwise you may have recordings interrupted by unwanted calls. Using the MightyMic W with MoviePro for video recording 	Product warranty is limited to original defects in material and workmanship. Warranty does not cover collateral damage due to misuse, abuse, incorrect charging and other inappropriate uses of this product and are not covered under the warranty. See details at ampridge.com for complete info. 6. Technical specifications		 Why isn't there a signal even when the Microphone is powered on? Ans: Ensure the battery is fully charged up to 6 hours before using for the first time. The LED will light when it starts charging. There is no sound during playback. Ans: The default playback is through the jack on the MightyMic. Check the connection between your device and your
 is activated Using the button on the bottom of the microphone set it 	Using the Mightymic W with MoviePro for Video recording	Parameter	Value	phone, if the connection is not established, please
to the pairing mode In the Settings App on the iPhone select the Bluetooth	 If the Bluetooth microphone is connected before the app starts, on starting you will see the text "Bluetooth Microphone." 	Bluetooth Specification	Bluetooth 4.0	reconnect again. Make sure the Microphone is paired and connected with your target phone or other device.
 option. Look for a Bluetooth device listed as "Ampridge" Select the device listed as "Ampridge" to pair it to the 	 If the Bluetooth microphone is connected after the app starts, the microphone is changed to a Bluetooth microphone and the text 	Bluetooth Profile	HFP1.6/A2DP1.2/ AVRCP1.4/HSP1.2	3. Can the microphone connect with a second phone? Ans: Yes, it can, please set the Microphone to multipoint
microphone. The display should change from "Not	"Bluetooth Microphone" appears	RF Range	Approx 30 feet (10m)	mode. Connect the Microphone to phone A, then
Paired" to "Connected" • You can use the MightyMic W to play music as well as to	 If the Bluetooth Microphone is disconnected while the app is active, the app switches to the built-in microphone and the text 	Frequency Response	20Hz-20KHz	once again enter into the pairing mode (phone A, will disconnect), and connect the Microphone to phone B.
control the music player functions such as volume up, next song, etc.	"Built-in Microphone" appears. 4) To confirm the microphone is connected do a test recording or go	Receiver Output	20mW	Then use the phone A paired device list to reconnect to the Microphone.
<u>.</u>	into the Settings section. Upon leaving the Settings section the Bluetooth microphone will become active again and the	Signal-To-Noise	≥85dB	Warning:
4.3 Charging your Bluetooth Microphone	"Bluetooth Microphone" message will appear again.	Distortion	≤1.0%	You must select a qualified charger from a reliable manufacturer
This Microphone uses a USB to 3.5mm 4pin charging cable. Use a USB charger (not included) to charge your device.	 Playback of the sound will occur through the headphone jack on the MightyMic W while connected via Bluetooth. 	Playback Time	4-5 hours	 Do not use the USB charger cable on any other device because of possible damage
Make sure that your device is full charged for at least 6	Many updates are planned for Bluetooth options to further	Charging Time	About 2 hours	 Unit contains Li-ion polymer batteries. Li-ion Polymer batteries are volatile. Failure to read and follow the safety instructions may result
hours before initial use. Insert one terminal of your charger cable to a USB charger or USB port of a PC and connect the	enhance the features. Please check the website for updates regarding this or other features.	Dimension(L×W×H)	58×16.6×12.7MM	in fire, personal injury and damage to property if charged or used improperly. By purchasing and using this unit the buyer assumes all
other terminal to the 3.5mm audio jack. While charging, the red LED on the bottom will remain on.	Using the MightyMic W for audio recording	Weight	24g	risks associated with Li-ion batteries. Please dispose of properly.
When charging is completed, the LED will turn blue.	Osing the mightymic will support audio recording The MightyMic W will support audio App's designed to work with external Bluetooth devices.	7. Service and Support		iPhone [®] and iPad [®] are registered trademarks of Apple Inc. The Bluetooth [®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc
	 An audio App is needed such as Voice Recorder HD to do Bluetooth audio recording. Please check our website for updates regarding this or other supported Apps. 	If your device is not performing as it should please visit our website at ampridge.com or e-mail us at info@ampridge.com		
4	5	6		7